

YAMAHA

TW125'99

5EK1-AE1

SERVICE MANUAL

EAS00000

**TW125
SERVICE MANUAL**

©1998 by Yamaha Motor Co., Ltd.

1st Edition, July 1998

**All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.**

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha motorcycle has a basic understanding of the mechanical ideas and the procedures of motorcycle repair. Repairs attempted by anyone without this knowledge are likely to render the motorcycle unsafe and unfit for use.

Yamaha Motor Company, Ltd., is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the motorcycle operator, a bystander or a person inspecting or repairing the motorcycle.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the motorcycle.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and inspection procedures are laid out with the individual steps in sequential order.

- ① The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to “SYMBOLS” on the following page.
- ② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 (“Periodic Inspections and Adjustments”), where the sub-section title(-s) appear. (In Chapter 3, “Periodic Inspections and Adjustments”, the sub-section title appears at the top of each page, instead of the section title.)
- ③ Sub-section titles appear in smaller print than the section title.
- ④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.
- ⑤ Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.
- ⑥ Symbols indicate parts to be lubricated or replaced (see “SYMBOLS”).
- ⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- ⑧ Jobs requiring more information (such as special tools and technical data) are described sequentially.

CLUTCH ENG

⑤

⑥

⑦

CLUTCH ENG

REMOVING THE CLUTCH

1. Straighten the lock washer tab ①.

2. Loosen:

- clutch boss nut ②

NOTE:

While holding the clutch boss ③ with the universal clutch holder ④, loosen the clutch boss nut.

Universal clutch holder
90890-04086

3. Remove:

- clutch boss nut ①
- lock washer ②
- clutch boss ③
- thrust washer ④
- clutch housing ⑤

⑧

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:

- friction plate

Damage/wear → Replace the friction plates as a set.

2. Measure:

- friction plate thickness

Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.

Friction plate thickness
2.9 – 3.1 mm
◀ Limit: 2.7 mm

CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.



1. Check:

- clutch plate

Damage → Replace the clutch plates as a set.

4-31

4-35

① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ CARB 	⑥ CHAS 	
⑦ ELEC 	⑧ TRBL SHTG 	
⑨ 	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	⑲ 
⑳ 	㉑ 	㉒ 
㉓ 	㉔ 	

EAS00009

SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic inspections and adjustments
- ④ Engine
- ⑤ Carburetor(-s)
- ⑥ Chassis
- ⑦ Electrical system
- ⑧ Troubleshooting

Symbols ⑨ to ⑯ indicate the following.

- ⑨ Serviceable with engine mounted
- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Tightening torque
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Electrical data

Symbols ⑰ to ㉒ in the exploded diagrams indicate the types of lubricants and lubrication points.


- ⑰ Engine oil
- ⑱ Gear oil
- ⑲ Molybdenum disulfide oil
- ㉑ Wheel bearing grease
- ㉒ Lithium soap base grease
- ㉓ Molybdenum disulfide grease

Symbols ㉓ to ㉔ in the exploded diagrams indicate the following:

- ㉓ Apply locking agent (LOCTITE®)
- ㉔ Replace the part

INDEX

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC INSPECTION AND ADJUSTMENT	
	CHK ADJ 3
ENGINE OVERHAUL	
	ENG 4
CARBURATION	
	CARB 5
CHASSIS	
	CHAS 6
ELECTRICAL	
	ELEC 7
TROUBLESHOOTING	?
	TRBL SHTG 8




**GEN
INFO**

1

CHAPTER 1.

GENERAL INFORMATION

MOTORCYCLE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL CODE	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY	1-2
REPLACEMENT PARTS	1-2
GASKETS, OIL SEALS AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS	1-3
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-3
CHECKING THE CONNECTIONS	1-4
SPECIAL TOOLS	1-5




EAS00014

GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

EAS00017

VEHICLE IDENTIFICATION NUMBER


The vehicle identification number ① is stamped into the right side of the steering head.



EAS00018

MODEL CODE


The model code label ① is affixed to the frame. This information will be needed to order spare parts.



EAS00020

IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DIS- ASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to the "SPECIAL TOOLS" section.
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.



EAS00021


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EAS00022

GASKETS, OIL SEALS AND O-RINGS


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and apply grease onto the oil seal lips.



EAS00023

LOCK WASHERS/PLATES AND COTTER PINS

1. After removal, replace all lock washers/plates① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EAS00024


BEARINGS AND OIL SEALS

1. Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, apply a light coat of lithium soap base grease onto the oil seal lips. Oil bearings liberally when installing, if appropriate.


- ① Oil seal

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



- ① Bearing



EAS00025

CIRCLIPS

1. Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure that the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

- ④ Shaft



EAS00026

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:

- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.

3. Check:

- all connections

Loose connection → Connect properly.

NOTE:

If the pin ① on the terminal is flattened, bend it up.

4. Connect:

- lead
- coupler
- connector

NOTE:

Make sure that all connections are tight.

5. Check:





- continuity
(with a pocket tester)



Pocket tester
90890-03112

NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps 1 to 3.
- As a quick remedy, use a contact revitalizer available at most part stores.





EAS00020

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques.

When placing an order, refer to the list provided below to avoid any mistakes.

Tool No.	Tool name/Usage	Illustration
90890-01080 -04052	Rotor puller Attachment These tools are used when removing the generator rotor.	
90890-01083 -01084	Rocker arm shaft puller bolt Weight These tools are used when removing or installing the rocker arm shafts.	
90890-01268	Ringnut wrench This tool is used to loosen and tighten the exhaust and steering ringnut.	
90890-01294 -01326	Damper rod holder T-handle This tool is used for disassembling or assembling the front fork	
90890-01311	Valve adjusting tool This tool is necessary for adjusting valve clearance.	
90890-01312	Fuel level gauge This gauge is used to measure the fuel level in the float chamber.	
90890-01367 -01368	Fork seal driver weight Fork seal driver attachment (ø33 mm) This tool is used when installing the fork seal.	
90890-01403	Ring nut wrench This tool is used to loosen and tighten the steering ring nut.	
90890-01701	Sheave holder This tool is used for holding the generator rotor	

SPECIAL TOOLS

**GEN
INFO**






Tool No.	Tool name/Usage	Illustration
90890-03079	Thickness gauge This tool is used to measure the valve clearance.	
90890-03081 -04082	Compression gauge Adaptor These tools are used to measure the engine compression.	
90890-03112	Pocket tester These instruments are invaluable for checking the electrical system.	
90890-03113	Engine tachometer This tool is needed for detecting engine rpm.	
90890-03141	Timing light This tool is necessary for checking ignition timing.	
90890-04019 -04108	Valve spring compressor Attachment These tools are used when removing or installing the valve and the valve spring.	
90890-04064	Valve guide remover 6 mm This tool is used to remove the valve guide.	
90890-04065	Valve guide reamer 6 mm This tool is used to rebores the valve guide.	
90890-04066	Valve guide installer 6 mm This tool is needed to install the valve guides properly.	
90890-04086	Clutch holding tool This tool is used for holding the clutch boss.	

SPECIAL TOOLS

GEN
INFO



Tool No.	Tool name/Usage	Illustration
90890-04101	Valve lapper This tool is used for lapping the valve.	
90890-06754	Ignition checker This instrument is necessary for checking the ignition system components.	
90890-85505	Yamaha bond No.1215 This sealant (bond) is used for crankcase mating surface, etc.	





SPEC

2


CHAPTER 2. SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-4
ENGINE	2-4
CHASSIS	2-9
ELECTRICAL	2-12
CONVERSION TABLE	2-14
CONVERSION TABLE	2-14
GENERAL TORQUE SPECIFICATIONS	2-14
LUBRICATION POINT AND GRADE OF LUBRICANT	2-15
ENGINE	2-15
CHASSIS	2-16
LUBRICATION DIAGRAM	2-17
CABLE ROUTING	2-19



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	TW125
Model code:	5EK1/5EK2
Dimensions: Overall length Overall width Overall height Seat height Wheelbase Minimum ground clearance Minimum turning radius	2,140 mm 810 mm 1,120 mm 805 mm 1,330 mm 260 mm 2,100 mm
Basic weight: With oil and full fuel tank	125 kg
Engine: Engine type Cylinder arrangement Displacement Bore × stroke Compression ratio Compression pressure (STD) Starting system Lubrication system:	Air-cooled 4-stroke, SOHC Forward-inclined single cylinder 0.124 L (124 cm ³) 57.0 × 48.8 mm 10.0 : 1 1,200 kPa (12.0 kg/cm ² , 12.0 bar) at 1,000 r/min Electric starter Wet sump
Oil type or grade: Engine oil  Periodic oil change With oil filter replacement Total amount	API standard: “SE” or higher grade ACEA standard: G4 or G5 1.0 L 1.1 L 1.3 L
Air filter:	Wet type element
Fuel: Type Fuel tank capacity Fuel reserve capacity	Regular unleaded gasoline 7.0 L 1.0 L

GENERAL SPECIFICATIONS

SPEC



Model	TW125
Carburetor: Type/quantity Manufacturer	Y24P/1 TEIKEI
Spark plug: Type Manufacturer Spark plug gap	DR8EA NGK 0.6 ~ 0.7 mm
Clutch type:	Wet, multiple-disc
Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio 1st 2nd 3rd 4th 5th	Spur gear 74/20 (3.700) Chain drive 50/14 (3.571) Constant mesh 5 speed Left foot operation 36/16 (2.250) 31/21 (1.476) 27/24 (1.125) 25/27 (0.926) 23/29 (0.793)
Chassis: Frame type Caster angle Trail	Diamond 26° 95 mm
Tire: Type Size front Size rear Manufacture front Manufacture rear Type front Type rear	Tube type 130/80-18 66P 180/80-14 M/C 78P BRIDGESTONE BRIDGESTONE TW31 TW34
Tire pressure (cold tire): Maximum load-except motorcycle Loading condition A * front rear Loading condition B * front rear Off road riding front rear High speed riding front rear	180 kg 0 ~ 80 kg 150 kPa (1.5 kg/cm ² , 1.5 bar) 150 kPa (1.5 kg/cm ² , 1.5 bar) 80 ~ 180 kg 150 kPa (1.5 kg/cm ² , 1.5 bar) 175 kPa (1.75 kg/cm ² , 1.75 bar) 125 kPa (1.25 kg/cm ² , 1.25 bar) 125 kPa (1.25 kg/cm ² , 1.25 bar) 150 kPa (1.5 kg/cm ² , 1.5 bar) 175 kPa (1.75 kg/cm ² , 1.75 bar)

*Load is the total weight of cargo, rider, passenger, and accessories.

GENERAL SPECIFICATIONS

SPEC








Model	TW125
Brake: Front brake type operation Rear brake type operation	Single disc brake Right hand operation Drum brake Right foot operation
Suspension: Front suspension Rear suspension	Telescopic fork Swingarm (Monocross)
Shock absorber: Front shock absorber Rear shock absorber	Coil spring/Oil damper Coil gas spring/Oil damper
Wheel travel: Front wheel travel Rear wheel travel	160 mm 150 mm
Electrical: Ignition system Generator system Battery type Battery capacity	C.D.I. C.D.I. magneto GM 7CZ-3D 12 V 7 AH
Headlight type:	Bulb type
Bulb wattage × quantity: Headlight Auxiliary light Tail/brake light Turn signal light Meter light High beam indicator Neutral indicator Turn signal indicator	12 V 45 W/40 W × 1 12 V 4 W × 1 12 V 5 W/21 W × 1 12 V 21 W × 4 12 V 3.4 W × 1 12 V 3.4 W × 1 12 V 3.4 W × 1 12 V 3.4 W × 1



MAINTENANCE SPECIFICATIONS

ENGINE


Item	Standard	Limit
Cylinder head: Warp limit	...	0.05 mm
Cylinder: Bore size	57.00 ~ 57.02 mm	57.1 mm
Taper limit	...	0.05 mm
Out of runout limit	...	0.01 mm
Camshaft: Cam dimensions Intake "A" "B" "C" Exhaust "A" "B" "C" Camshaft runout limit	 36.54 ~ 36.64 mm 30.13 ~ 30.23 mm 6.59 mm 36.58 ~ 36.68 mm 30.21 ~ 30.31 mm 6.63 mm ...	 36.45 mm 30.05 mm ... 36.49 mm 30.13 mm ... 0.03 mm
Cam chain: Cam chain type/No. of links Cam chain adjustment	DID 25SH/104 EDESOLES Automatic	
Rocker arm/rocker armshaft: Rocker arm inside diameter Rocker shaft outside diameter Rocker arm-to-rocker armshaft clearance	 12.000 ~ 12.018 mm 11.985 ~ 11.991 mm 0.009 ~ 0.033 mm	 12.036 mm 11.950 mm ...
Valve, valve seat, valve guide: Valve clearance (cold) Valve dimensions	IN 0.05 ~ 0.09 mm EX 0.11 ~ 0.15 mm    	
"A" head diameter	IN 28.9 ~ 29.1 mm EX 23.9 ~ 24.1 mm	
"B" face width	IN 2.4 ~ 2.8 mm EX 2.4 ~ 2.8 mm	
"C" seat width	IN 0.9 ~ 1.1 mm EX 0.9 ~ 1.1 mm	
"D" margin thickness	IN 0.8 ~ 1.2 mm EX 0.8 ~ 1.2 mm	
Stem outside diameter	IN 5.975 ~ 5.990 mm EX 5.960 ~ 5.975 mm	5.955 mm 5.940 mm


MAINTENANCE SPECIFICATIONS

SPEC



Item		Standard	Limit
Guide inside diameter	IN	6.000 ~ 6.012 mm	6.042 mm
	EX	6.000 ~ 6.012 mm	6.042 mm
Stem-to-guide clearance	IN	0.010 ~ 0.037 mm	0.08 mm
	EX	0.025 ~ 0.052 mm	0.10 mm
Stem runout limit		...	0.03 mm
Valve seat width	IN	0.9 ~ 1.1 mm	1.6 mm
	EX	0.9 ~ 1.1 mm	1.6 mm
Valve spring:			
Free length	(inner) IN/EX	35.5 mm	33.5 mm
	(outer) IN/EX	37.2 mm	35.2 mm
Set length (valve closed)	(inner) IN/EX	30.5 mm	...
	(outer) IN/EX	32.0 mm	...
Compressed pressure	(inner) IN/EX	8.4 ~ 10.2kg	...
	(outer) IN/EX	16.6 ~ 20.4 kg	...
Tilt limit (inner)	IN/EX	...	2.5°/1.5 mm
Tilt limit (outer)	IN/EX	...	2.5°/1.6 mm
Direction of winding	(inner) IN/EX	Clockwise	...
	(outer) IN/EX	Counterclockwise	...
Piston:			
Piston to cylinder clearance		0.035 ~ 0.055 mm	...
Piston size "D"		56.960 ~ 56.975 mm	...
Piston over size (1st)		57.25 mm	...
Piston over size (2nd)		57.50 mm	...
Measuring point "H"		7.0 mm	...
Piston off-set		0.5 mm	...
Piston off-set direction		IN side	...
Piston pin bore inside diameter		15.002 ~ 15.013 mm	15.045 mm
Piston pin outside diameter		14.987 ~ 14.992 mm	14.975 mm
Piston rings:			
Top ring:			
Type		Plane	...
Dimensions (B × T)		2.3 × 2.5 mm	...
End gap (installed)		0.15 ~ 0.35 mm	0.60 mm
Side clearance (installed)		0.03 ~ 0.07 mm	0.15 mm
2nd ring:			
Type		Plane	...
Dimensions (B × T)		2.3 × 2.5 mm	...
End gap (installed)		0.15 ~ 0.35 mm	0.60 mm
Side clearance		0.02 ~ 0.06 mm	0.15 mm
Oil ring:			
Dimensions (B × T)		2.5 × 2.8 mm	...
End gap (installed)		0.3 ~ 0.9 mm	...







MAINTENANCE SPECIFICATIONS

SPEC



TIGHTENING TORQUES ENGINE

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque		Remarks
				Nm	m•kg	
Cylinder head blind plug	Screw	M6	2	7	0.7	
Cylinder head and cylinder	Bolt	M8	4	22	2.2	
Cylinder head (Timing chain side)	Bolt	M8	2	20	2.0	
Cam sprocket cover	Screw	M6	2	7	0.7	
Valve cover	Bolt	M6	5	10	1.0	
Camshaft retainer	Bolt	M6	2	8	0.8	
Spark plug	—	M12	1	18	1.8	
Cylinder	Bolt	M6	2	10	1.0	
Balancer driven gear	Nut	M14	1	50	5.0	
C.D.I. magneto	Bolt	M10	1	50	5.0	
Valve adjuster locknut	Nut	M6	2	14	1.4	
Cam sprocket	Bolt	M10	1	60	6.0	
Timing chain tensioner	Bolt	M6	2	10	1.0	
Timing chain guide (intake)	Bolt	M6	2	8	0.8	
Oil pump	Screw	M6	2	7	0.7	
Oil pump and crankcase	Screw	M6	3	7	0.7	
Drain plug	Bolt	M35	1	43	4.3	
Oil filter cover	Screw	M6	2	7	0.7	
Drain bolt (oil filter)	Bolt	M6	1	10	1.0	
Carburetor joint and carburetor	Bolt	M6	2	12	1.2	
Air filter case (front)	Bolt	M6	1	10	1.0	
Air filter case (rear)	Bolt	M6	2	10	1.0	
Muffler protector	Screw	M6	4	7	0.7	
Muffler and frame	Bolt	M8	2	20	2.0	
	Bolt	M8	1	27	2.7	
Exhaust pipe and cylinder	Bolt	M6	2	12	1.2	
Exhaust pipe and muffler	Screw	M8	1	20	2.0	
Crankcase (left and right)	Screw	M6	13	7	0.7	
Generator cover	Screw	M6	10	7	0.7	
Crankcase cover (left)	Screw	M4	1	2	0.2	
Clutch cover	Screw	M6	11	7	0.7	
Starter clutch	Bolt	M8	3	30	3.0	
Primary drive gear	Nut	M14	1	50	5.0	
Clutch spring	Screw	M5	4	6	0.6	
Clutch boss	Nut	M14	1	70	7.0	
Push lever axle	Screw	M8	1	12	1.2	
Push lever adjuster	Nut	M6	1	8	0.8	
Drive sprocket	Bolt	M5	2	6	0.6	
Shift cam (Segment)	Screw	M6	1	12	1.2	
Shift pedal	Bolt	M6	1	10	1.0	
Pick up coil	Screw	M6	2	7	0.7	
Neutral switch	Screw	M10	1	20	2.0	
Stator coil	Screw	M6	3	7	0.7	
Starter motor	Screw	M6	1	7	0.7	

Item	Standard	Limit
Tightening sequence Cylinder head		
Crankcase		

MAINTENANCE SPECIFICATIONS

SPEC



CHASSIS

Item	Standard	Limit
Steering system:		
Steering bearing type (upper)	Ball bearings	...
(lower)	Angular ball bearing	...
No./size of steel balls (upper)	22 pcs. 0.1875 in	...
Front suspension:		
Front fork travel	160 mm	...
Fork spring free length	342 mm	338 mm
Fitting length	337 mm	...
Spring rate (K1)	4.4 N /mm (0.44 kg/mm)	...
Stroke (K1)	0 ~ 160 mm	...
Oil capacity	0.243 L (243 cm ³)	...
Oil level	135 mm	...
Oil grade	Fork oil 10 WT or equivalent	...
Inner tube vend limit	...	0.2 mm
Rear suspension:		
Shock absorber stroke	48 mm	...
Spring free length	193 mm	173 mm
Fitting length	185 mm	...
Spring rate (K1)	100 N/mm (10.0 kg/mm)	...
Stroke (K1)	0 ~ 48 mm	...
Front wheel:		
Type	Spoke wheel	...
Rim size	2.50 × 18	...
Rim material	Aluminum	...
Rim runout limit radial	...	2 mm
lateral	...	2 mm
Rear wheel:		
Type	Spoke wheel	...
Rim size	14 M/C × MT 4.50	...
Rim material	Steel	...
Rim runout limit radial	...	2 mm
lateral	...	2 mm
Drive chain:		
Type/manufacturer	428HG/DAIDO	...
No. of links	109	...
Chain free play	35 ~ 60 mm	...
Front brake:		
Type	Single disc	...
Disc outside diameter	220 mm	...
Disc thickness	3.5 mm	3.0 mm
Pad thickness (inner)	5.3 mm	0.8 mm
(outer)	5.3 mm	0.8 mm
Master cylinder inside diameter	11 mm	...
Caliper cylinder 1 inside diameter	26.9 mm	...
Caliper cylinder 2 inside diameter	22.2 mm	...
Brake fluid type	DOT#4	...

MAINTENANCE SPECIFICATIONS

SPEC



Item	Standard	Limit
Rear brake:		
Type	Leading, trailing	...
Drum inside diameter	110 mm	111 mm
Shoe thickness	4 mm	2 mm
Shoe spring free length	50.5 mm	...
Brake lever:		
Brake lever free play (at lever end)	2 ~ 5 mm	...
Brake pedal:		
Brake pedal free play	20 ~ 30 mm	...
Brake pedal position	30 mm	...
Clutch lever:		
Clutch lever free play (at lever end)	10 ~ 15 mm	...
Throttle cable free play	3 ~ 5 mm	...

TIGHTENING TORQUES

CHASSIS

Part to be tightened	Thread size	Tightening torque		Remarks
		Nm	m•kg	
Handle crown and front fork	M8	23	2.3	Refer to NOTE
Handle crown and steering shaft	M14	90	9.0	
Handlebar holder (under and upper)	M8	20	2.0	
Steering ring nut	M25	18	1.8	
Master cylinder (front brake)	M6	7	0.7	
Brake hose union bolt (front brake)	M10	26	2.6	
Steering shaft and front fork	M10	30	3.0	
Engine and front engine stay	M8	33	3.3	
Front engine stay and frame	M8	33	3.3	
Engine and top engine stay	M8	33	3.3	
Top engine stay and frame	M8	33	3.3	
Engine and frame	M8	33	3.3	
Swingarm pivot shaft	M12	80	8.0	
Rear shock absorber and frame	M10	56	5.6	
Chain guide and swingarm	M5	5	0.5	
Sidestand	M10	40	4.0	
Footrest (left)	M12	60	6.0	
(right)	M10	45	4.5	
Rear footrest (left)	M8	15	1.5	
Front wheel axle and nut	M14	90	9.0	
Rear wheel axle and nut	M16	90	9.0	
Brake caliper and front fork	M10	30	3.0	
Brake disc and front wheel	M6	13	1.3	
Rear wheel sprocket and hub	M8	35	3.5	
Brake caliper bleed screw	M7	6	0.6	
Brake cam lever	M6	9	0.9	

NOTE:

1. When tighten the ring nut, should be steady the ball bearings and the steering shaft moving smoothly.
2. First, tighten the ring nut approximately 38 Nm (3.8 m•kg) by using the torque wrench, then loosen the ring nut one turn and retighten the ring nut to specification.



ELECTRICAL

Item	Standard	Limit
Ignition timing: Ignition timing (B.T.D.C.) Advanced timing Advanced type	9° at 1,500 r/min 30° at 5,000 r/min Digital type	
C.D.I.: Pickup coil resistance/color Source coil resistance/color C.D.I. unit model/manufacturer	656 ~ 984 Ω at 20°C/ Red – White 624 ~ 936 Ω at 20°C/ Brown – Green 5EK/YAMAHA	
Ignition coil: Model/ manufacturer Minimum spark gap Primary winding resistance Secondary winding resistance	2JN/YAMAHA 6 mm 0.18 ~ 0.28 Ω at 20°C 6.32 ~ 9.48 kΩ at 20°C	
Spark plug cap: Type Resistance	Resin type 10 kΩ	
Charging system: Type Model/manufacturer Standard output Stator coil resistance/color	C.D.I. magneto F5BT/YAMAHA 12V 170 W/5,000 r/min 0.48 ~ 0.72 Ω at 20°C/ White – White	
Rectifier/regulator: Model/manufacturer Type (regulator) No load regulated voltage Capacity (rectifier) Withstand voltage	SH629A-12/SHINDENGEN Semi conductor-short circuit type 14.5 V 10 A 200 V	
Battery: Specific gravity	1.280	...
Electric starter system: Type Starter motor: Model/ manufacturer Output Armature coil resistance Brush overall length Brush spring pressure Commutator diameter Mica undercut (depth)	Constant mesh type 2JX/YAMAHA 0.4 kW 0.0171 ~ 0.0209 Ω at 20°C 10 mm 5.52 ~ 8.28 N (552 ~ 828 g) 22 mm 1.5 mm	 3.5 mm ... 21 mm ...

MAINTENANCE SPECIFICATIONS

SPEC



Item	Standard	Limit
Starter relay:		
Model/manufacturer	MS5F/JIDECO	...
Amperage rating	100 A	...
Coil winding resistance	4.2 ~ 4.6 Ω at 20°C	...
Horn:		
Model/manufacturer	YF-12/NIKKO	...
Maximum amperage	3 A	...
Flasher relay:		
Type	Full transistor type	...
Model/manufacturer	FE 246 BH/DENSO	...
Flasher frequency	85 cycle/min	...
Circuit breaker:		
Type	Fuse	...
Main	20 A $\times$ 1 pcs.	...
Reserve	20 A $\times$ 1 pcs.	...

CONVERSION TABLE/ GENERAL TORQUE SPECIFICATIONS

**GEN
INFO**



EAS00028

CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.
Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER		IMP
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in


CONVERSION TABLE

METRIC TO IMP			
	Known	Multiplier	Result
Torque	m•kg	7.233	ft•lb
	m•kg	86.794	in•lb
	cm•kg	0.0723	ft•lb
	cm•kg	0.8679	in•lb
Weight	kg	2.205	lb
	g	0.03527	oz
Distance	km/hr	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu•in
	lit (liter)	0.8799	qt (IMP liq.)
	lit (liter)	0.2199	gal (IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade	9/5 (°C) + 32	Fahrenheit (°F)

EAS00029

GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.



A: Distance across flats

B: Outside thread diameter

A (Nut)	B (Bolt)	General torque specifications	
		Nm	m•kg
10 mm	6 mm	6	0.6
12 mm	8 mm	15	1.5
14 mm	10 mm	30	3.0
17 mm	12 mm	55	5.5
19 mm	14 mm	85	8.5
22 mm	16 mm	130	13.0

LUBRICATION POINT AND GRADE OF LUBRICANT

SPEC



LUBRICATION POINT AND GRADE OF LUBRICANT ENGINE

Lubrication Point	Symbol
Oil seal lips (all)	
Bearing retainer (all)	
Bolt (cylinder head)	
Crank pin	
Connecting rod (big end)	
Piston pin	
Piston/piston ring	
Buffer boss	
Valve stem/valve guide (IN, EX)	
Valve stem end (IN, EX)	
Rocker arm shaft	
Cam and bearing (camshaft)	
Rocker arm inner surface	
Crankcase mating surfaces	Yamaha bond No.1215
O-ring (all)	
Starter idle gear thrust surfaces	
Starter clutch (outer/roller)	
Starter wheel gear inner surface	
Push rod	
Primary driven gear inner surface	
Push lever axle	
Transmission gear inner surface	
Shift fork/guide bar/shaft	
Shift cam	

LUBRICATION POINT AND GRADE OF LUBRICANT

SPEC




CHASSIS

Lubrication Point	Symbol
Steering head pipe bearing (upper/lower)	
Front wheel oil seal lips (left/right)	
Rear wheel oil seal lips (left/right)	
Rear brake shoe plate, camshaft and pivoting pin	
Pivoting points (brake pedal shaft and frame)	
Sidestand sliding surface/mounting bolt	
Tube guide (throttle grip) inner surface	
Brake lever bolt/master cylinder sliding surface	
Clutch lever bolt/collar/cable sliding surface	
Brake pedal shaft surface	
Gear unit (speedometer)	
Swigarm insert surface/bush/thrust cover	
Pivot shaft surface	
Rear shock absorber lower pin surface/dust seal lips	


**LUBRICATION DIAGRAM**

- ① Rocker arm (IN)
- ② Rocker shaft
- ③ Rocker arm (EX)
- ④ Camshaft
- ⑤ Oil pump
- ⑥ Push lever





- ① Oil pump
- ② Oil filter
- ③ Crankshaft
- ④ Main axle
- ⑤ Drive axle
- ⑥ Oil strainer






CABLE ROUTING

- ① Brake hose
- ② Throttle cable
- ③ Front brake switch lead
- ④ Handlebar switch lead (right)
- ⑤ Handlebar switch lead (left)
- ⑥ Clutch cable
- ⑦ Clutch switch lead
- ⑧ Main switch lead
- ⑨ Speedometer cable
- ⑩ Starter cable
- ⑪ Indicator light lead

- ⑫ Meter lead
- ⑬ Headlight coupler
- ⑭ Wireharness
- ⑮ Front turn signal light (right)
- ⑯ Front turn signal light lead (right)

- A Fasten the handlebar switch lead, front brake switch lead and clutch switch lead to the handlebar with a plastic clamp.
- B The end of the plastic locking tie must face down ward.
- C To headlight






- ① Battery positive lead
- ② Starter relay
- ③ Starter motor lead
- ④ Clamp
- ⑤ Front brake switch lead
- ⑥ Handlebar switch lead (right)
- ⑦ Ignition coil
- ⑧ Horn lead
- ⑨ High tension cable
- ⑩ Flasher relay
- ⑪ Rear brake switch lead
- ⑫ Neutral relay
- ⑬ CDI unit

- [A] The end of the plastic locking tie must face down ward.
- [B] Fasten the wire harness, handlebar switch lead (right), front brake switch lead, throttle cable, starter cable, clutch switch lead and main switch lead to the frame with steel clamp.
- [C] Route the wire harness, handlebar switch (right) and front brake switch lead through the cable guide.
- [D] Route the battery breather hose through the cable guide.

- [E] Route the battery breather hose through the hole of air cleaner case.
- [F] Fasten the rear brake switch lead couplers and carburetor heater lead to the frame with a plastic locking tie. The end of the plastic locking tie must face front side.






- ① Starter cable
- ② Throttle cable
- ③ Clutch switch lead
- ④ Main switch lead
- ⑤ Thermo switch lead
- ⑥ Sidestand switch lead
- ⑦ Carburetor over flow hose
- ⑧ Carburetor air vent hose
- ⑨ Clutch cable
- ⑩ Brake hose
- ⑪ Speedometer cable
- ⑫ CDI magneto leads
- ⑬ Neutral switch lead


- [A] Fasten the CDI magneto leads, starter motor lead, neutral switch lead and ground lead to the frame stay. The end of plastic locking tie must face down ward.
- [B] Fasten the side stand switch lead with the steel clamp.
- [C] Fasten the carburetor air vent hose, carburetor over flow hose and starter motor lead with a plastic clamp.
- [D] Route the side stand switch lead through the guide.

- [E] Route the carburetor air vent hose and carburetor over flow hose between the engine and swingarm.
- [F] Route the starter motor lead between the engine and swing arm.






- G** Route the carburetor air vent hose and carburetor over flow hose through the guide.
- H** Route the clutch cable through the cable guide.
- I** Route the brake hose and speedometer cable through the cable guide.
- J** Fasten the brake hose and speedometer cable to the front fork outer tube with a cable holder.






- ① Clutch switch lead
- ② Main switch lead
- ③ Starter motor lead
- ④ CDI magneto lead
- ⑤ Battery positive lead
- ⑥ Wire harness
- ⑦ Thermo switch lead
- ⑧ Sidestand switch lead
- ⑨ Battery negative lead
- ⑩ Rectifier/Regulator
- ⑪ Ground lead


- A Fasten the wire harness with steel clamp.
- B Fasten the wire harness and rear turn signal light lead to the frame with a plastic locking tie. The end of plastic locking tie must face in side.
- C Route the rear turn signal light lead inside of hose.
- D Fasten the wire harness and rear turn signal light (right) with a steel clamp.
- E Route the rear turn signal light lead (right) between the frame and license bracket.
- F Route the rear turn signal light lead (left) between the frame and license bracket.





- G** Fasten the rear turn signal light (left) to the frame with a plastic locking tie. The end of plastic locking tie must face rear ward.
- H** Fasten the thermo switch lead connectors to the frame with a plastic locking tie. The end of plastic locking tie must face inside.





CHK

ADJ

3

CHAPTER 3.

PERIODIC INSPECTIONS AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION INTERVALS	3-1
SEAT, FUEL TANK AND SIDE COVER	3-3
ENGINE	3-4
ADJUSTING THE VALVE CLEARANCE	3-4
ADJUSTING THE ENGINE IDLING SPEED	3-6
ADJUSTING THE THROTTLE CABLE FREE PLAY	3-7
CHECKING THE SPARK PLUG	3-8
CHECKING THE IGNITION TIMING	3-9
MEASURING THE COMPRESSION PRESSURE	3-10
CHECKING THE ENGINE OIL LEVEL	3-11
CHANGING THE ENGINE OIL	3-12
ADJUSTING THE CLUTCH CABLE FREE PLAY	3-14
CLEANING THE AIR FILTER ELEMENT	3-15
CHECKING THE CARBURETOR JOINT AND INTAKE MANIFOLD	3-16
CHECKING THE FUEL HOSES	3-16
CHECKING THE CRANKCASE BREATHER HOSE	3-17
CHECKING THE EXHAUST SYSTEM	3-17
CHASSIS	3-19
ADJUSTING THE FRONT BRAKE	3-19
ADJUSTING THE REAR BRAKE	3-19
CHECKING THE BRAKE FLUID LEVEL	3-21
CHECKING THE BRAKE PADS	3-22
CHECKING THE BRAKE SHOES	3-22
ADJUSTING THE REAR BRAKE LIGHT SWITCH	3-22
CHECKING THE BRAKE HOSE	3-23
BLEEDING THE HYDRAULIC BRAKE SYSTEM	3-23
ADJUSTING THE DRIVE CHAIN SLACK	3-24
LUBRICATING THE DRIVE CHAIN	3-26
CHECKING AND ADJUSTING THE STEERING HEAD	3-26
CHECKING THE FRONT FORK	3-28
CHECKING THE TIRES	3-28
CHECKING AND TIGHTENING THE SPOKES	3-31
CHECKING AND LUBRICATING THE CABLES	3-31
LUBRICATING THE LEVERS AND PEDALS	3-32
LUBRICATING THE SIDESTAND	3-32
LUBRICATING THE REAR SUSPENSION	3-32
ELECTRICAL SYSTEM	3-33
CHECKING THE BATTERY	3-33
CHECKING THE FUSE	3-36
REPLACING THE HEADLIGHT BULB	3-37
ADJUSTING THE HEADLIGHT BEAM	3-38



EAS00036

PERIODIC INSPECTIONS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EAS00037

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

No	ITEM	ROUTINE	BRAKE- IN 1,000 KM	EVERY	
				6,000 km or 6 months	12,000 km or 12 months
1	* Fuel line	- Check fuel hoses for cracks or damage. - Replace if necessary.		√	√
2	Spark plugs	- Check condition. - Clean, regap or replace if necessary.	√	√	√
3	* Valves	- Check valve clearance. - Adjust if necessary.	√	√	√
4	Air filter	Clean or replace if necessary.		√	√
5	* Battery	- Check electrolyte level and specific gravity. - Correct or recharge if necessary. - Make sure that the breather hose is properly routed.		√	√
6	Clutch	- Check operation. - Adjust or replace cable.	√	√	√
7	* Front brake	- Check operation, fluid level and vehicle for fluid leakage. (See NOTE) - Correct accordingly. - Replace brake pads if necessary.	√	√	√
8	* Rear brake	- Check operation. - Adjust cable and replace brake shoes if necessary.	√	√	√
9	* Wheels	- Check balance, runout spoke tightness and for damage. - Tighten spokes and rebalance, replace if necessary.		√	√
10	* Tires	- Check tread depth and for damage. - Replace if necessary. - Check air pressure. - Correct if necessary.		√	√
11	* Wheel bearings	- Check bearing for looseness or damage. - Replace if necessary.		√	√
12	* Swingarm	- Check Swingarm pivoting point for play. - Correct if necessary. - Lubricate with lithium soap base grease.		√	√
13	Drive chain	- Check chain slack. - Adjust if necessary. Make sure that the rear wheel is properly aligned. - Clean and lubricate.	Every 500 km and after washing the motorcycle or riding in rain		
14	* Steering bearings	- Check bearing play and steering for roughness. - Correct accordingly. - Lubricate with lithium soap base grease every 24,000 km or 24 months (whichever comes first).		√	√

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

CHK
ADJ



NO.	ITEM	ROUTINE	BRAKE-IN 1,000 KM	EVERY	
				6,000 km or 6 months	12,000 km or 12 months
15	*	Chassis fasteners	- Make sure that all nuts, bolts and screws are properly tightened. - Tighten if necessary.	√	√
16		Sidestand	- Check operation. - Lubricate and repair if necessary.	√	√
17	*	Sidestand switch	- Check operation. - Replace if necessary.	√	√
18	*	Front fork	- Check operation and for oil leakage. - Correct accordingly.	√	√
19	*	Rear shock absorber assembly pivoting points	- Check operation. - Lubricate with lithium soap base grease every 24,000 km or 24 months (whichever comes first).	√	√
20	*	Carburetor	- Check engine idling speed and starter operation. - Adjust if necessary.	√	√
21		Engine oil	- Check oil level and vehicle for oil leakage. - Correct if necessary. - Change. (Warm engine before draining.)	√	√
22		Engine oil filter element	Clean or replace if necessary.	√	√
23	*	Engine oil strainer	Clean or replace if necessary.	√	√


*: Since these items require special tools, date and technical skills, they should be serviced by a Yamaha dealer.

NOTE:

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake system.
 - When disassembling the master cylinder or caliper cylinder, always replace the brake fluid. Check the brake fluid level regularly and fill as required.
 - Replace the oil seals on the inner parts of the master cylinder and caliper cylinder every two years.
 - Replace the brake hoses every four years or if cracked or damaged.




SEAT, FUEL TANK AND SIDE COVER



Order	Job/Part	Q'ty	Remarks
	Removing the seat, fuel tank and side cover		Remove the parts in the order listed.
1	Seat	1	NOTE: _____ Before disconnecting the fuel hose, turn the fuel cock off.
2	Fuel hose	1	
3	Fuel tank	1	For installation, reverse the removal procedure.
4	Tail cover	1	
5	Side cover (left)	1	
6	Side cover (right)	1	

ADJUSTING THE THROTTLE CABLE FREE PLAY

CHK
ADJ



EAS00058

ADJUSTING THE THROTTLE CABLE FREE PLAY

NOTE:

Prior to adjusting the throttle cable free play, the engine idling speed should be adjusted.

1. Check:

- throttle cable free play (a)
Out of specification → Adjust.



Throttle cable free play (at the flange of the throttle grip)
3 ~ 5 mm

2. Adjust:

- throttle cable free play

Carburetor side

- Loosen the locknut (1) on the throttle cable.
- Turn the adjusting nut (2) in direction (a) or (b) until the specified throttle cable free play is obtained.


Direction (a) → Throttle cable free play is increased.

Direction (b) → Throttle cable free play is decreased.

- Tighten the locknut.

NOTE:

If the specified throttle cable free play cannot be obtained on the carburetor side of the cable, use the adjusting nut on the handlebar side.




Handlebar side

- Loosen the locknut (1).
- Turn the adjusting nut (2) in direction (a) or (b) until the specified throttle cable free play is obtained.

Direction (a) → Throttle cable free play is increased.

Direction (b) → Throttle cable free play is decreased.

- Tighten the locknut.



ADJUSTING THE THROTTLE CABLE FREE PLAY/ CHECKING THE SPARK PLUG

CHK
ADJ



⚠ WARNING

After adjusting the throttle cable free play, turn the handlebar to the right and to the left to ensure that this does not cause the engine idling speed to change.



EAS00060

CHECKING THE SPARK PLUG

1. Disconnect:
 - spark plug cap
2. Remove:
 - spark plug


CAUTION:

Before removing the spark plug, blow away any dirt accumulated in the spark plug well with compressed air to prevent it from falling into the cylinder.

3. Check:
 - spark plug type
Incorrect → Change.



Spark plug type (manufacturer)
DR8EA (NGK)



4. Check:
 - electrode ①
Damage/wear → Replace the spark plug.
 - insulator ②
Abnormal color → Replace the spark plug.
Normal color is a medium-to-light tan color.
5. Clean:
 - spark plug
(with a spark plug cleaner or wire brush)
6. Measure:
 - spark plug gap @
(with a wire gauge)
Out of specification → Regap.



Spark plug gap
0.6 ~ 0.7 mm



EAS00067

MEASURING THE COMPRESSION PRESSURE

NOTE:

Insufficient compression pressure will result in a loss of performance.

1. Check:

- valve clearance

Out of specification → Adjust

Refer to "ADJUSTING THE VALVE CLEARANCE".

2. Start the engine, warm it up for several minutes, and then turn it off.

3. Disconnect:


- spark plug cap

4. Remove:

- spark plug

CAUTION:

Before removing the spark plug, use compressed air to blow away any dirt accumulated in the spark plug well to prevent it from falling into the cylinder.



5. Install:

- compression gauge ①



Compression gauge ①

90890-03081

Adapter ②

90890-04082

6. Measure:

- compression pressure

Above the maximum pressure → Inspect the cylinder head, valve surfaces, and piston crown for carbon deposits.

Below the minimum pressure → Squirt a few drops of oil into the cylinder and measure again.

- Refer to the following table.

Compression pressure (with oil applied into cylinder)	
Reading	Diagnosis
Higher than without oil	Piston wear or damage → Repair.
Same as without oil	Piston ring(-s), valves, cylinder head gasket or piston possibly defective → Repair.



8. Fill:

- crankcase

(with the specified amount of the recommended engine oil)



Quantity

Total amount

1.3 L

Without oil filter element replacement

1.0 L

With oil filter element replacement

1.1 L

9. Install:

- engine oil filler cap

10. Start the engine, warm it up for several minutes, and then turn it off.


11. Check:

- engine
(for engine oil leaks)

12. Check:

- engine oil level

Refer to "CHECKING THE ENGINE OIL LEVEL".



13. Check:

- engine oil pressure



a. Slightly loosen the oil gallery bolt ①.

b. Start the engine and keep it idling until the engine oil starts to seep from the oil gallery bolt.

If no engine oil comes out after one minute, turn the engine off so that it will not seize.

c. Check engine oil passages and oil pump for damage or leakage.

d. Start the engine after solving the problem(s), and check the oil pressure again.

e. Tighten the oil gallery bolt to specification.



Oil gallery bolt:

7 Nm (0.7 m•kg)



CLEANING THE AIR FILTER ELEMENT

CHK
ADJ




EAS00090

CLEANING THE AIR FILTER ELEMENT

1. Remove:

- side cover (left)
- air filter case cover ①



2. Remove:



- air filter element ①

3. Clean:

- air filter element
(with solvent)

NOTE:

After cleaning, carefully pat the air filter element on a clean cloth to remove the excess oil.



4. Check:

- air filter element
Damage → Replace.

5. Apply the recommended oil to the entire surface of the air filter element and then carefully pat the air filter element on a clean cloth to remove the excess oil. The air filter element should be wet but not dripping.



Recommended oil
Engine oil

6. Install:

- air filter element
- air filter case cover
(along with the gasket)

CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect the carburetor tuning, leading to poor engine performance and possible overheating.




NOTE:

- Make sure that the air filter element is properly installed in the air filter case.
- The air filter screen fits into the slots ② in the air filter case.

7. Install:

- side cover (left)



EAS00094

**CHECKING THE CARBURETOR JOINT AND
INTAKE MANIFOLD**

1. Remove:

- seat
- side cover
- fuel tank

Refer to "SEAT, FUEL TANK AND SIDE COVER".

2. Check:

- carburetor joint ①
- intake manifold ②

Cracks/damage → Replace.

Refer to "CARBURETOR" in chapter 5.

3. Install:

- fuel tank
- side cover
- seat

Refer to "SEAT, FUEL TANK AND SIDE COVER".

EAS00096


CHECKING THE FUEL HOSES

The following procedure applies to all of the fuel and vacuum hoses.

1. Remove:

- seat
- side cover
- fuel tank

Refer to "SEAT, FUEL TANK AND SIDE COVER".



2. Check:

- fuel hose ①

Cracks/damage → Replace.

Loose connection → Connect properly.

3. Install:

- fuel tank
- side cover
- seat

Refer to "SEAT, FUEL TANK AND SIDE COVER".

CHECKING THE CRANKCASE BREATHER HOSE/ CHECKING THE EXHAUST SYSTEM

CHK
ADJ




EAS00098

CHECKING THE CRANKCASE BREATHER HOSE

1. Remove:

- seat
- side cover
- fuel tank

Refer to "SEAT, FUEL TANK AND SIDE COVER".



2. Check:

- crankcase breather hose ①
- Cracks/damage → Replace.
Loose connection → Connect properly.

CAUTION:

Make sure that the crankcase breather hose is routed correctly.

3. Install:

- fuel tank
- side cover
- seat

Refer to "SEAT, FUEL TANK AND SIDE COVER".


EAS00100

CHECKING THE EXHAUST SYSTEM

The following procedure applies to all of the exhaust pipes, mufflers and gaskets.

1. Remove:

- seat
- rear cowling
- side cover (right)




2. Check:

- exhaust pipe ①
 - silencer ②
- Cracks/damage → Replace.
- gasket ③
- Exhaust gas leaks → Replace.

CHECKING THE EXHAUST SYSTEM

CHK
ADJ



3. Check:
- tightening torque



Exhaust pipe ④

12 Nm (1.2 m•kg)

Exhaust pipe and muffler bolt ⑤

20 Nm (2.0 m•kg)

Muffler and muffler bracket bolt ⑥

20 Nm (2.7 m•kg)


Muffler and muffler bracket bolt ⑦

27 Nm (2.7 m•kg)

4. Install:
- side cover (right)
 - rear cowling
 - seat

ADJUSTING THE FRONT BRAKE/ ADJUSTING THE REAR BRAKE

**CHK
ADJ**



EAS00108

CHASSIS

ADJUSTING THE FRONT BRAKE

1. Check:

- brake lever free play (a)
Out of specification → Adjust.



**Brake lever free play
(at the end of the brake lever):
2 ~ 5 mm**

2. Adjust:

- brake lever free play



- Loosen the locknut (1).
- Turn the adjusting bolt (2) in direction (b) or (c) until the specified free play is obtained.

Direction (b) → Brake lever free play is increased.

Direction (c) → Brake lever free play is decreased.

- Tighten the locknut.

⚠ WARNING

A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance and could result in loss of control and possibly an accident. Therefore, inspect and, if necessary, bleed the brake system.

CAUTION:

After adjusting the brake lever position, make sure that there is no brake drag.



EAS00112


ADJUSTING THE REAR BRAKE

1. Check:

- brake pedal position
(distance (a) from the top of the rider footrest to the top of the brake pedal)
Out of specification → Adjust.



**Brake pedal position (above the
top of the rider footrest)
30 mm**






EAS00115

CHECKING THE BRAKE FLUID LEVEL

1. Stand the motorcycle on a level surface.

NOTE:

- Place the motorcycle on a suitable stand.
- Make sure that the motorcycle is upright.



2. Check:

- brake fluid level

Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.



Recommended brake fluid
DOT 4

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

NOTE:

In order to ensure a correct reading of the brake fluid level, make sure that the top of the reservoir is horizontal.

CHECKING THE BRAKE HOSE/ BLEEDING THE HYDRAULIC BRAKE SYSTEM

CHK
ADJ



EAS00129

CHECKING THE BRAKE HOSE

1. Check:
 - brake hose ①
Cracks/damage/wear → Replace.
2. Check:
 - brake hose clamp
Loose connection → Tighten.
3. Hold the motorcycle upright and apply the front or rear brake.
4. Check:
 - brake hose
Activate the brake several times.
Brake fluid leakage → Replace the damaged hose.
Refer to “FRONT BRAKE” in chapter 6.

EAS00133

BLEEDING THE HYDRAULIC BRAKE SYSTEM

WARNING

Bleed the hydraulic brake system whenever:

- The system was disassembled.
- A brake hose was loosened or removed.
- The brake fluid level is very low.
- Brake operation is faulty.

NOTE:

- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir to overflow.
- When bleeding the hydraulic brake system, make sure that there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the hydraulic brake system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.

ADJUSTING THE DRIVE CHAIN SLACK

CHK
ADJ




1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.




2. Rotate the rear wheel several times and check the drive chain to locate its tightest point.

3. Measure:

- drive chain slack
- Out of specification → Adjust.



Drive chain slack
35 ~ 60 mm



4. Adjust:

- drive chain slack



- a. Loosen the wheel axle nut ①.
- b. Turn the chain pullers ② in direction (a) or (b) until the specified drive chain slack is obtained.

Direction (a) → Drive chain is tightened.

Direction (b) → Drive chain is loosened.

NOTE:

To maintain the proper wheel alignment, adjust both sides evenly.

- c. Tighten the wheel axle nut.



Wheel axle nut
90 Nm (9.0 m•kg)




CAUTION:

Do not loosen the wheel axle nut after tightening it to the specified torque. If the groove in the wheel axle nut is not aligned with the cotter pin hole in the wheel axle, tighten the nut further until they are aligned.

CHECKING AND ADJUSTING THE STEERING HEAD

CHK
ADJ



- b. Loosen the lower ring nut (4) and then tighten it to specification with a ring nut wrench (5).

NOTE:

Set the torque wrench at a right angle to the ring nut wrench.



Ring nut wrench
90890-01403



Lower ring nut
(initial tightening torque)
38 Nm (3.8 m•kg)


- c. Loosen the lower ring nut completely, then tighten it to specification.

⚠ WARNING

Do not overtighten the lower ring nut.



Lower ring nut (final tightening torque)
18 Nm (1.8 m•kg)



- d. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and inspect the upper and lower bearings.

Refer to "STEERING HEAD AND HANDLEBAR" in chapter 6.

- e. Install the rubber washer.
f. Install the upper ring nut (6).
g. Finger tighten the upper ring nut (6), then align the slots of both ring nuts. If necessary, hold the lower ring nut and tighten the upper ring nut until their slots are aligned.
h. Install the lock washer (7).

NOTE:

Make sure that the lock washer tabs (a) sit correctly in the ring nut slots (b).

5. Install:

- upper bracket
- handlebar



Steering stem nut
90 Nm (9.0 m•kg)
Upper bracket pinch bolt
23 Nm (2.3 m•kg)
Handlebar holder bolt
20 Nm (2.0 m•kg)



EAS00149

CHECKING THE FRONT FORK

1. Stand the motorcycle on a level surface.


⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

2. Check:


- inner tube
Damage/scratches → Replace.
- oil seal
Oil leakage → Replace.

3. Hold the motorcycle upright and apply the front brake.



4. Check:

- operation
Push down hard on the handlebar several times and check if the front fork rebounds smoothly.
Unsmooth operation → Repair.
Refer to "FRONT FORK" in chapter 6.



EAS00166

CHECKING THE TIRES

The following procedure applies to both of the tires.

1. Measure:

- tire pressure
Out of specification → Regulate.

⚠ WARNING

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded motorcycle could cause tire damage, an accident or an injury.

NEVER OVERLOAD THE MOTORCYCLE.

CHECKING THE TIRES

CHK
ADJ




Basic weight (with oil and a full fuel tank)	125 kg	
Maximum load*	180 kg	
Cold tire pressure	Front tire	Rear tire
Up to 80 kg load*	150 kPa (1.50kgf/cm ² , 1.5 bar)	150 kPa (1.50kgf/cm ² , 1.5 bar)
80 kg ~ maximum load*	150 kPa (1.50 kgf/cm ² , 1.5 bar)	175 kPa (1.75 kgf/cm ² , 1.75 bar)
Off road riding	125 kPa (1.25 kgf/cm ² , 1.25 bar)	125kPa (1.25 kgf/cm ² , 1.25 bar)

*: total of cargo, rider, passenger and accessories

WARNING

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.



2. Check:

- tire surfaces
Damage/wear → Replace the tire.



Minimum tire tread depth
1.6 mm

- ① Tire tread depth
- ② Side wall
- ③ Wear indicator

WARNING

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using tube tires, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure that the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.

Tube wheel →	Tube tire only
Tubeless wheel →	Tube or tubeless tire

- After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this motorcycle.

Front tire

Manufacturer	Type	Size
BRIDGESTONE	TW31	130/80-18 66P

Rear tire




Manufacturer	Type	Size
BRIDGESTONE	TW34	180/80-14 M/C 78P

 WARNING

- After mounting a new tire, ride conservatively for a while to become accustomed to the “feel” of the new tire and to allow the tire to seat itself properly in the rim. Failure to do so could lead to an accident with possible injury to the rider or damage to the motorcycle.
- After a tire has been repaired or replaced, be sure to tighten the tire valve stem locknut ① to specification.

NOTE:


- For tires with a direction of rotation mark ①:
- Install the tire with the mark pointing in the direction of wheel rotation.
 - Align the mark ② with the valve installation point.



Tire valve stem locknut
1.5 Nm (0.15 m•kg)

CHECKING AND TIGHTENING THE SPOKES/ CHECKING AND LUBRICATING THE CABLES

CHK
ADJ



EAS00169

CHECKING AND TIGHTENING THE SPOKES

The following procedure applies to all of the spokes.

1. Check:

- spoke ①
Bends/damage → Replace.
Loose → Tighten.
Tap the spokes with a screwdriver.

NOTE:

A tight spoke will emit a clear, ringing tone; a loose spoke will sound flat.

2. Tighten:

- spoke
(with a spoke wrench ②)

NOTE:

Be sure to tighten the spokes before and after break-in.



Spoke nipple
2 Nm (0.2 m•kg)

EAS00170

CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the cable sheaths and cables.



WARNING

Damaged cable sheaths may cause the cable to corrode and interfere with its movement. Replace damaged cable sheaths and cables as soon as possible.

1. Check:

- cable sheath
Damage → Replace.

2. Check:

- cable operation
Unsmooth operation → Lubricate.



Recommended lubricant
Engine oil or a suitable cable lubricant

NOTE:

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubing device.

LUBRICATING THE LEVERS AND PEDALS/LUBRICATING THE SIDESTAND/LUBRICATING THE REAR SUSPENSION

CHK
ADJ



EAS00171

LUBRICATING THE LEVERS AND PEDALS

Lubricate the pivoting point and metal-to-metal moving parts of the levers and pedals.



Recommended lubricant
Engine oil

EAS00172

LUBRICATING THE SIDESTAND

Lubricate the pivoting point and metal-to-metal moving parts of the sidestand.



Recommended lubricant
Engine oil

EAS00174

LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.



Recommended lubricant
Molybdenum disulfide oil



EAS00176

ELECTRICAL SYSTEM CHECKING THE BATTERY

⚠ WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

First aid in case of bodily contact:

External

- SKIN – Wash with water.
- EYES – Flush with water for 15 minutes and get immediate medical attention.

Internal

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

1. Remove:


- seat
- side cover (right)

2. Disconnect:

- battery leads (from the battery terminals)
- battery breather hose

CAUTION:

First, disconnect the negative lead ①, then the positive lead ②.





3. Remove:

- battery

CHECKING THE BATTERY

CHK
ADJ



4. Check:

- electrolyte level

The electrolyte level should be between the minimum level mark ① and the maximum level mark ②.

Below the minimum level mark → Add distilled water to the proper level.

CAUTION:

Add only distilled water. Tap water contains minerals which are harmful to the battery.

5. Check:

- specific gravity

Less than 1.280 → Recharge the battery.

Specific gravity
1.280 at 20°C

6. Charge:

- battery

Battery charging amperage and time
0.7 amps/10 hrs

⚠ WARNING

Do not quick charge a battery.

CAUTION:

- Loosen the battery sealing caps.
- Make sure that the battery breather hose and battery vent are free of obstructions.
- To ensure maximum performance, always charge a new battery before using it.
- Do not use a high-rate battery charger. They force a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the motorcycle. (If charging has to be done with the battery mounted on the motorcycle, disconnect the negative lead from the battery terminal.)
- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.



- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure that the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!

NOTE:

Replace the battery whenever:

- battery voltage does not rise to specification or bubbles fail to rise during charging,
- sulphation of one or more battery cells occurs (as indicated by the battery plates turning white or material accumulating in the bottom of the battery cell),
- specific gravity readings after a long, slow charge indicate that one battery cell's charge is lower than the rest,
- warpage or buckling of the battery plates or insulators is evident.

7. Check:

- battery breather hose and battery vent
Obstruction → Clean.
Damage → Replace.

8. Install:


- battery


9. Connect:

- battery breather hose ①

CAUTION:

- When inspecting the battery, make sure that the battery breather hose is properly attached and routed correctly. If the battery breather hose is positioned so as to allow electrolyte or hydrogen gas from the battery to contact the frame, the motorcycle and its finish may be damaged.
- Make sure that the battery breather hose is properly routed away from the drive chain and from below the swingarm.





ENG

4

CHAPTER 4. OVERHAULING THE ENGINE

ENGINE	4-1
LEAD AND EXHAUST PIPE	4-1
CARBURETOR AND DRIVE SPROCKET	4-2
ENGINE	4-3
INSTALLING THE ENGINE	4-4
 CYLINDER HEAD	4-5
CAMSHAFT SPROCKET COVER	4-5
CYLINDER HEAD	4-6
REMOVING THE CYLINDER HEAD	4-7
CHECKING THE CYLINDER HEAD	4-7
CHECKING THE TIMING CHAIN TENSIONER	4-8
CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER	4-8
INSTALLING THE CYLINDER HEAD	4-8
INSTALLING THE CAMSHAFT SPROCKET	4-9
 CAMSHAFT	4-12
REMOVING THE ROCKER ARMS AND CAMSHAFT	4-13
CHECKING THE CAMSHAFTS	4-13
CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS ..	4-14
INSTALLING THE CAMSHAFT AND ROCKER ARMS	4-15
 VALVES AND VALVE SPRINGS	4-17
REMOVING THE VALVES	4-18
CHECKING THE VALVES AND VALVE GUIDES	4-19
CHECKING THE VALVE SEATS	4-20
CHECKING THE VALVE SPRINGS	4-22
INSTALLING THE VALVES	4-23
 CYLINDER AND PISTON	4-24
REMOVING THE PISTON AND PISTON RINGS	4-25
CHECKING THE CYLINDER AND PISTON	4-25
CHECKING THE PISTON RINGS	4-26
CHECKING THE PISTON PIN	4-27
INSTALLING THE PISTON AND CYLINDER	4-28
 CLUTCH	4-30
CLUTCH COVER	4-30
CLUTCH	4-31
REMOVING THE CLUTCH	4-33
CHECKING THE FRICTION PLATES	4-33
CHECKING THE CLUTCH PLATES	4-33
CHECKING THE CLUTCH SPRINGS	4-34
CHECKING THE CLUTCH HOUSING	4-34
CHECKING THE CLUTCH BOSS	4-34
CHECKING THE CLUTCH PUSH RODS	4-35

INSTALLING THE CLUTCH	4-35
SHIFT SHAFT AND STOPPER LEVER	4-38
CHECKING THE SHIFT SHAFT	4-40
CHECKING THE STOPPER LEVER	4-40
INSTALLING THE SEGMENT	4-40
INSTALLING THE SHIFT SHAFT	4-41
OIL PUMP	4-42
REMOVING THE PROMARY GEAR	4-44
CHECKING THE OIL PUMP	4-44
ASSEMBLING THE OIL PUMP	4-45
INSTALLING THE OIL PUMP	4-45
INSTALLING THE PRIMARY DRIVE GEAR	4-46
BALANCER GEAR	4-47
REMOVING THE BALANCER DRIVEN GEAR	4-48
CHECKING THE BALANCER DRIVE GEAR	4-48
ASSEMBLING THE BALANCER DRIVE GEAR	4-48
INSTALLING THE BALANCER DRIVEN GEAR	4-49
STARTER CLUTCH AND GENERATOR	4-50
GENERATOR COVER	4-50
STATOR COIL	4-51
STARTER CLUTCH AND GENERATOR	4-52
REMOVING THE GENERATOR ROTOR	4-53
CHECKING THE STARTER CLUTCH	4-53
INSTALLING THE STARTER CLUTCH	4-54
INSTALLING THE GENERATOR ROTOR	4-55
CRANKSHAFT	4-56
CRANKCASE	4-56
CRANKSHAFT AND BALANCER WEIGHT	4-58
DISASSEMBLING THE CRANKCASE	4-59
REMOVING THE PLUNGER SEAL	4-59
CHECKING THE CRANKSHAFT AND CONNECTING ROD	4-60
CHECKING THE BEARINGS AND OIL SEALS	4-61
CHECKING THE TIMING CHAIN, CAMSHAFT SPROCKET, AND TIMING CHAIN GUIDES	4-61
INSTALLING THE PLUNGER SEAL	4-61
INSTALLING THE CRANKSHAFT	4-62
ASSEMBLING THE CRANKCASE	4-62
TRANSMISSION	4-63
TRANSMISSION, SHIFT DRUM ASSEMBLY AND SHIFT FORKS	4-63
DRIVE AXLE AND MAIN AXLE	4-64
REMOVING THE TRANSMISSION	4-65
CHECKING THE SHIFT FORKS	4-65
CHECKING THE SHIFT DRUM ASSEMBLY	4-65


CHECKING THE TRANSMISSION	4-66
INSTALLING THE TRANSMISSION, SHIFT FORKS AND SHIFT DRUM ASSEMBLY	4-67



EAS00188

OVERHAULING THE ENGINE

ENGINE LEAD AND EXHAUST PIPE




Order	Job/Part	Q'ty	Remarks
	Disconnecting the leads and hoses Seat, fuel tank and side cover Battery lead		Disconnect the parts in the order listed. Refer to "SEAT, FUEL TANK AND SIDE COVER" in CHAPTER 3. CAUTION: _____ First, disconnect the negative lead, then the positive lead.
1	Generator coupler/starter motor coupler	1/1	
2	Plug cap	1	
3	Muffler	1	
4	Exhaust pipe	1	
5	Gasket	1	For connecting, reverse the disconnection procedure.



EAS00189

CARBURETOR AND DRIVE SPROCKET




Order	Job/Part	Q'ty	Remarks
	Removing the carburetor and drive sprocket		Remove the parts in the order listed.
1	Carburetor	1	Refer to "CARBURETOR" in CHAPTER 5.
2	Clutch cable	1	
3	Crankcase breather hose	1	
4	Ground lead	1	
5	Shift pedal	1	
6	Generator cover	1	
7	Rear wheel axle nut	1	NOTE: _____ Loosen the axle nut and slacken the drive chain.
8	Sprocket holder	1	
	Drive sprocket/drive chain	1/1	For installation, reverse the removal procedure.







EAS00192

ENGINE



Order	Job/Part	Q'ty	Remarks
	Removing the engine		
1	Engine stay (top)	1	Remove the parts in the order listed. Securely support the motorcycle so there is no danger of it falling over.
2	Front engine stay	1	
3	Pivot shaft	1	Refer to "INSTALLING THE ENGINE."
4	Engine mount bolt (rear under)	1	
5	Engine	1	
			For installation, reverse the removal procedure.



EAS00192

INSTALLING THE ENGINE**1. Install:**

- pivot shaft ①
- engine mount bolt (rear) ②
- engine mount bolt (front) ③
- engine mount bolt (front) ④
- engine mount bolt (top) ⑤
- engine bracket bolt (front) ⑥
- engine bracket bolt (front) ⑦
- engine bracket bolt (top) ⑧
- engine bracket bolt (top) ⑨

NOTE:

Do not fully tighten the bolts.


2. Tighten the bolts in the following order.**Pivot shaft ①****80 Nm (8.0 m•kg)****Engine mount bolt (rear) ②****33 Nm (3.3 m•kg)****Engine mount bolt (front) ③****33 Nm (3.3 m•kg)****Engine mount bolt (front) ④****33 Nm (3.3 m•kg)****Engine mount bolt (top) ⑤****33 Nm (3.3 m•kg)****Engine bracket bolt (front) ⑥****33 Nm (3.3 m•kg)****Engine bracket bolt (front) ⑦****33 Nm (3.3 m•kg)****Engine bracket bolt (top) ⑧****33 Nm (3.3 m•kg)****Engine bracket bolt (top) ⑨****33 Nm (3.3 m•kg)****3. Install:**

- shift pedal ①

**10 Nm (1.0 m•kg)**



CYLINDER HEAD
CAMSHAFT SPROCKET COVER




Order	Job/Part	Q'ty	Remarks
	Removing the camshaft sprocket cover		Remove the parts in the order listed.
	Side cover, seat and fuel tank		☐ Refer to "SEAT, FUEL TANK AND SIDE COVER" in CHAPTER 3.
	Exhaust pipe assembly		☐ Refer to "ENGINE."
	Carburetor assembly		☐ Refer to "CARBURETOR" in CHAPTER 5.
	Engine stay (top)		☐ Refer to "ENGINE."
1	Spark plug	1	
2	Camshaft sprocket cover/O-ring	1/1	
3	Valve cover (intake side)/O-ring	1/1	
4	Valve cover (exhaust side)/O-ring	1/1	
5	Intake manifold/O-ring	1/1	
6	Timing mark cap/O-ring	1/1	
7	Center cap/O-ring	1/1	
			For installation, reverse the removal procedure.




EAS00221

CYLINDER HEAD



Order	Job/Part	Q'ty	Remarks
	Removing the cylinder head		
1	Timing chain tensioner assembly	1	Remove the parts in the order listed. Refer to "REMOVING THE CYLINDER HEAD/INSTALLING THE CAMSHAFT SPROCKET".
2	Camshaft sprocket/Timing chain	1/1	
3	Cylinder head	1	
4	Dowel pins	3	Refer to "REMOVING/INSTALLING THE CYLINDER HEAD".
5	Gasket	1	
6	Cylinder head gasket	1	
			For installation, reverse the removal procedure.



EAS00216

CHECKING THE TIMING CHAIN TENSIONER

1. Check:

- timing chain tensioner
- Cracks/damage → Replace.

EAS00212

CHECKING THE TAPPET COVERS AND CAMSHAFT SPROCKET COVER

The following procedure applies to both of the tappet covers and O-rings.

1. Check:

- tappet cover
- camshaft sprocket cover
- O-ring

Damage/wear → Replace the defective part(-s).

EAS00233



INSTALLING THE CYLINDER HEAD

1. Install:

- dowel pins ①
- O-ring ②
- gasket (New) ③

NOTE:

The "UP" mark on the gasket must face up.



2. Install:

- cylinder head


NOTE:

- Apply engine oil onto the threads of the cylinder head nuts.
- Tighten the cylinder head nuts in the proper tightening sequence as shown and torque them in two stages.

**Cylinder head nut**

M8 (① ~ ④) 22Nm (2,2m•kg)

M8 (⑤ ~ ⑥) 20Nm (2,0m•kg)



EAS00213

INSTALLING THE CAMSHAFT SPROCKET**1. Align:**


- "I" mark on the generator rotor
(with the mark on the generator rotor cover)



- Turn the crankshaft counterclockwise.
- When the piston is at TDC on the compression stroke, align the "I" mark (a) on the generator rotor with the mark (b) on the generator rotor cover.

NOTE:

Be sure to keep the timing chain as tight as possible.

**2. Install:**

- timing chain
(onto the camshaft sprocket)
- camshaft sprocket
(onto the camshaft)


NOTE:

The notch (a) on the camshaft should face towards the intake side of the engine.

Align the camshaft marks (a) with the edge of the cylinder head as shown.

CAUTION:

Do not turn the crankshaft when installing the camshaft to avoid damage or improper valve timing.

**3. Install:**


- washer (1)
- camshaft sprocket bolts (2)

60 Nm (6.0 m•kg)




EAS00195

CAMSHAFT




Order	Job/Part	Q'ty	Remarks
	Removing the camshaft		
	Cylinder head		Remove the parts in the order listed. Refer to "CYLINDER HEAD".
1	Lock washer	1	Refer to "REMOVING THE ROCKER ARMS AND CAMSHAFT/INSTALLING THE CAMSHAFT AND ROCKER ARMS".
2	Camshaft retainer	1	
3	Camshaft bushing	1	
4	Camshaft	1	
5	Rocker arm shaft (intake side)	1	
6	Rocker arm shaft (exhaust side)	1	
7	Rocker arm	2	
8	O-ring	1	
9	Nut/Adjuster	2/2	For installation, reverse the removal procedure.




EAS00202

REMOVING THE ROCKER ARMS AND CAM-SHAFT**1. Loosen:**

- locknuts ①
- adjusting screws ②

**2. Remove:**


- bolt ①
- lock washer ②
- camshaft retainer ③

**3. Remove:**

- camshaft ①
- camshaft bushing ②

NOTE:


Screw a 10-mm bolt ③ into the threaded end of the camshaft and then pull out the camshaft.

**4. Remove:**

- intake rocker arm shaft
- exhaust rocker arm shaft
- intake rocker arm
- exhaust rocker arm

NOTE:

Attach a rocker arm shaft puller bolt ① and weight ② to the rocker arm shaft and slide out the shaft.

**Rocker arm shaft puller bolt****90890-01083****Weight****90890-01084**


EAS00205

CHECKING THE CAMSHAFTS**1. Check:**

- camshaft bushings
- Damage/wear → Replace.

2. Check:

- camshaft lobes
- Blue discoloration/pitting/scratches → Replace the camshaft.



3. Measure:

- camshaft lobe dimensions **A** and **B**
Out of specification → Replace the camshaft.

**Camshaft lobe dimension limit****Intake**




- A** 36.45 mm
- B** 30.05 mm

Exhaust

- A** 36.49 mm
- B** 30.13 mm

4. Check:

- camshaft oil passage
Obstruction → Blow out with compressed air.



EAS00206

CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS

The following procedure applies to all of the rocker arms and rocker arm shafts.

1. Check:

- rocker arm
Damage/wear → Replace.

2. Check:

- rocker arm shaft
Blue discoloration/excessive wear/pitting/scratches → Replace or check the lubrication system.

3. Check:

- camshaft lobe
Excessive wear → Replace the camshaft.

4. Measure:

- rocker arm inside diameter
Out of specification → Replace.

**Rocker arm inside diameter**

12.000 ~ 12.018 mm
Limit 12.036 mm

5. Measure:

- rocker arm shaft outside diameter
Out of specification → Replace.

**Rocker arm shaft outside diameter**

11.985 ~ 11.991 mm
Limit 11.950 mm



6. Calculate:

- rocker-arm-to-rocker-arm-shaft clearance

NOTE:

Calculate the clearance by subtracting the rocker arm shaft outside diameter from the rocker arm inside diameter.

Out of specification → Replace the defective part(-s).



Rocker-arm-to-rocker-arm-shaft clearance

0.009 ~ 0.033 mm

INSTALLING THE CAMSHAFT AND ROCKER ARMS

1. Lubricate:

- rocker arm shaft




Recommended lubricant
Molybdenum disulfide oil

2. Install:

- exhaust rocker arm
- exhaust rocker arm shaft

NOTE:

Make sure that the exhaust rocker arm shaft is completely pushed into the cylinder head.



3. Install:

- intake rocker arm
- intake rocker arm shaft ①

NOTE:

Insert a cylinder head bolt ② into the hole in the cylinder head and the intake rocker arm shaft as shown.

4. Lubricate:


- Camshaft



Recommended lubricant
Camshaft
Molybdenum disulfide oil
Camshaft bearing
Engine oil

CAMSHAFT

ENG



5. Install:

- camshaft retainer ①
- Lock washer ② **New**
- Bolt ③

 8 Nm (0.8 m•kg)

NOTE:

Bend the lock washer tab along a flat side of the bolt ③.


VALVES AND VALVE SPRINGS

ENG



EAS00236

VALVES AND VALVE SPRINGS



Order	Job/Part	Q'ty	Remarks
	Removing the valves and valve springs		Remove the parts in the order listed.
	Cylinder head		Refer to "CYLINDER HEAD".
	Rocker arm, Camshaft		Refer to "CAMSHAFT".
1	Valve cotters	4	Refer to "REMOVING/INSTALLING THE VALVES".
2	Spring retainer	2	
3	Valve spring (inner)	2	
4	Valve spring (outer)	2	
5	Valve (exhaust)	1	
6	Valve (intake)	1	
7	Valve guide (stem seal)	2	
8	Spring seat	2	
			For installation, reverse the removal procedure.






EAS00238

REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

NOTE:

Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure that the valves properly seal.



1. Check:

- valve sealing

Leakage at the valve seat → Check the valve face, valve seat, and valve seat width.

Refer to "CHECKING THE VALVE SEATS".



a. Pour a clean solvent (a) into the intake and exhaust ports.

b. Check that the valves properly seal.

There should be no leakage at the valve seat (1).



2. Remove:

- valve cotters (1)

NOTE:

Remove the valve cotters by compressing the valve springs with the valve spring compressor (2) and attachment (3).



Valve spring compressor

90890-04019

Attachment


90890-04108

3. Remove:

- upper spring seat (1)
- valve springs (2)
- oil seal (3)
- lower spring seat (4)
- valve (5)

NOTE:

Identify the position of each part very carefully so that it can be reinstalled in its original place.



EAS00239

CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

1. Measure:

- valve-stem-to-valve-guide clearance

$$\text{Valve-stem-to-valve-guide clearance} = \text{Valve guide inside diameter (a)} - \text{Valve stem diameter (b)}$$

Out of specification → Replace the valve guide.



Valve-stem-to-valve-guide clearance

Intake


0.010 ~ 0.037 mm

Limit: 0.08 mm

Exhaust

0.025 ~ 0.052 mm

Limit: 0.10 mm



2. Replace:

- valve guide

NOTE:

To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100°C in an oven.



a. Remove the valve guide with a valve guide remover (1).

b. Install the new valve guide with a valve guide installer (2) and valve guide remover (1).

c. After installing the valve guide, bore the valve guide with a valve guide reamer (3) to obtain the proper valve-stem-to-valve-guide clearance.

NOTE:

After replacing the valve guide, reface the valve seat.




Valve guide remover (6 mm)
90890-04064

Valve guide installer (6 mm)
90890-04065

Valve guide reamer (6 mm)
90890-04066




3. Eliminate:
 - carbon deposits
(from the valve face and valve seat)
4. Check:
 - valve face
Pitting/wear → Grind the valve face.
 - valve stem end
Mushroom shape or diameter larger than the body of the valve stem → Replace the valve.



5. Measure:
 - valve margin thickness (a)
Out of specification → Replace the valve.



Valve margin thickness
0.8 ~ 1.2 mm



6. Measure:
 - valve stem runout
Out of specification → Replace the valve.

NOTE:

- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the oil seal.




Valve stem runout
Limit: 0.03 mm

EAS00240






CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.

1. Eliminate:
 - carbon deposits
(from the valve face and valve seat)
2. Check:
 - valve seat
Pitting/wear → Replace the cylinder head.
3. Measure:
 - valve seat width (a)
Out of specification → Replace the cylinder head.



Valve seat width
Intake: 0.9 ~ 1.1 mm
Limit: 1.6 mm
Exhaust: 0.9 ~ 1.1 mm
Limit: 1.6 mm



- e. Apply a fine lapping compound to the valve face and repeat the above steps.
- f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.
- g. Apply Mechanic's blueing dye (Dykem) ② onto the valve face.
- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width ③ again. If the valve seat width is out of specification, reface and lap the valve seat.



EAS00241

CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.

1. Measure:
 - valve spring free length (a)
Out of specification → Replace the valve spring.



Valve spring free length (intake and exhaust)

Inner spring

35.5 mm Limit: 33.5 mm

Outer spring

37.2 mm Limit: 35.2 mm

2. Measure:
- compressed spring force (a)
Out of specification → Replace the valve spring.

⑥ Installed length



Compressed spring force

Intake and exhaust inner spring

8.4 ~ 10.2 kg at 30.5 mm

Intake and exhaust outer spring

16.6 ~ 20.4 kg at 32.0 mm

3. Measure:
- valve spring tilt @
Out of specification → Replace the valve spring.



Spring tilt limit

Intake and exhaust inner spring

2.5°/1.5 mm

Intake and exhaust outer spring

2.5°/1.6 mm



EAS00246

INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.

1. Deburr:

- valve stem end
(with an oil stone)

2. Lubricate:

- valve stem
- oil seal
(with the recommended lubricant)





Recommended lubricant
Molybdenum disulfide oil

3. Install:

- valve ①
- lower spring seat ②
- oil seal ③
- valve springs ④
- upper spring seat ⑤
(into the cylinder head)

NOTE:

Install the valve springs with the larger pitch a facing up.



4. Install:

- valve cotters ①

NOTE:

Install the valve cotters by compressing the valve springs with the valve spring compressor ② and attachment ③.




Valve spring compressor
90890-04019
Attachment
90890-04108

- ### 5. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a soft-face hammer.

CAUTION:


Hitting the valve tip with excessive force could damage the valve.






EAS00265

CYLINDER AND PISTON



Order	Job/Part	Q'ty	Remarks
	Removing the cylinder and piston		
	Cylinder head		Remove the parts in the order listed. Refer to "CYLINDER HEAD".
1	Timing chain guide (exhaust side)	1	
2	Cylinder/O-ring	1/1	
3	O-ring	1	Refer to "INSTALLING THE PISTON AND CYLINDER".
4	Dowel pin	2	
5	Cylinder gasket	1	
6	Piston pin circlip	2	Refer to "REMOVING THE PISTON AND PISTON RINGS".
7	Piston pin	1	Refer to "INSTALLING THE PISTON AND CYLINDER".
8	Piston	1	
9	Piston ring set	1	
			For installation, reverse the removal procedure.



- b. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.
- c. Measure piston skirt diameter "P" with the micrometer.

① 7.0 mm from the bottom edge of the piston.

	Piston size “P”
Standard	56.960 ~ 56.975 mm
Oversize 2	57.25 mm
Oversize 4	57.50 mm


- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

**Piston-to-cylinder clearance =
Cylinder bore “C” –
Piston skirt diameter “P”**



Piston-to-cylinder clearance
0.035 ~ 0.055 mm

- f. If out of specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.



EAS00263

CHECKING THE PISTON RINGS

1. Measure:
 - piston ring side clearance
Out of specification → Replace the piston and piston rings as a set.

NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.



Piston ring side clearance

Top ring


0.03 ~ 0.07 mm

<Limit>: 0.15 mm

2nd ring

0.02 ~ 0.06 mm

<Limit>: 0.15 mm



2. Install:
 - piston ring
(into the cylinder)

NOTE:

Level the piston ring in the cylinder with the piston crown as shown.

Ⓐ 5.0 mm

3. Measure:
 - piston ring end gap
Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.



Piston ring end gap

Top ring

0.15 ~ 0.35 mm

<Limit>: 0.60 mm


2nd ring

0.15 ~ 0.35 mm

<Limit>: 0.60 mm

Oil ring

0.3 ~ 0.9 mm



EAS00265

CHECKING THE PISTON PIN


1. Check:
 - piston pin
Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.
2. Measure:
 - piston pin outside diameter Ⓐ
Out of specification → Replace the piston pin.



Piston pin outside diameter

14.987 ~ 14.992 mm

3. Calculate:
 - piston-pin-to-piston clearance
Out of specification → Replace the piston pin and piston as a set.



Piston-pin-to-piston clearance =
Piston pin bore size (b) –
Piston pin outside diameter (a)



Piston-pin-to-piston clearance
0.010 ~ 0.026 mm

EAS00267



INSTALLING THE PISTON AND CYLINDER

1. Install:

- top ring ①
- 2nd ring ②
- lower oil ring rail ③
- upper oil ring rail ④
- oil ring expander ⑤

NOTE:

Be sure to install the piston rings so that the manufacturer's marks or numbers face up.




2. Install:

- piston ①
- piston pin ②
- piston pin clip ③ **New**

NOTE:

- Apply engine oil onto the piston pin.
- Make sure that the arrow mark (a) on the piston points towards the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the clip from falling into the crankcase.



3. Install:


- gasket ① **New**
- dowel pins ②

4. Lubricate:


- piston
- piston rings
- cylinder
(with the recommended lubricant)



Recommended lubricant
Engine oil



5. Offset:
- piston ring end gaps
- (a) Top ring
(b) Lower oil ring rail
(c) Upper oil ring rail
(d) 2nd ring



6. Install:
- cylinder ①


NOTE:

- While compressing the piston rings with one hand, install the cylinder with the other hand.
- Pass the timing chain and timing chain guide (exhaust side) through the timing chain cavity.



EAS00273

CLUTCH CLUTCH COVER




Order	Job/Part	Q'ty	Remarks
	Removing the clutch cover Drain the engine oil		Remove the parts in the order listed. Refer to "CHANGING THE ENGINE OIL" in CHAPTER 3.
1	Clutch cover	1	
2	Clutch cover gasket	1	
3	Dowel pins	2	For installation, reverse the removal procedure.




EAS00274



CLUTCH



Order	Job/Part	Q'ty	Remarks
	Removing the clutch		
1	Clutch springs	4	Remove the parts in the order listed.
2	Pressure plate	1	
3	Friction plates	4	Refer to "REMOVING/INSTALLING THE CLUTCH".
4	Clutch plates	3	
5	Nut/Lock washer	1/1	
6	Clutch boss	1	
7	Thrust washer	1	
8	Clutch housing	1	
9	Ball	1	
10	Long clutch push rod	1	
11	Push lever screw/Gasket	1/1	



Order	Job/Part	Q'ty	Remarks
12	Push lever axle	1	Refer to "INSTALLING THE CLUTCH".
13	Torsion spring	1	
14	Circlip	1	
15	Oil seal	1	
16	Nut/Washer	1/1	Refer to "INSTALLING THE CLUTCH".
17	Short clutch push rod/O-ring	1/1	
18	Push plate	1	For installation, reverse the removal procedure.



EAS00277

REMOVING THE CLUTCH

1. Straighten the lock washer tab ①.
2. Loosen:
 - clutch boss nut ②

NOTE:

While holding the clutch boss ③ with the universal clutch holder ④, loosen the clutch boss nut.



Universal clutch holder
90890-04086

3. Remove:
 - clutch boss nut ①
 - lock washer ②
 - clutch boss ③
 - thrust washer ④
 - clutch housing ⑤


EAS00280

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:
 - friction plate

Damage/wear → Replace the friction plates as a set.



2. Measure:
 - friction plate thickness

Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.



Friction plate thickness
2.9 ~ 3.1 mm
<Limit>: 2.7 mm


EAS00281

CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:
 - clutch plate

Damage → Replace the clutch plates as a set.



311-002

2. Measure:

- clutch plate warpage
(with a surface plate and thickness gauge
①)

Out of specification → Replace the clutch plates as a set.



Clutch plate warpage limit
Less than 0.05 mm


EAS00282

CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:

- clutch spring
Damage → Replace the clutch springs as a set.



2. Measure:

- clutch spring free length
Out of specification → Replace the clutch springs as a set.



Clutch spring free length
34.9 mm
<Limit>: 33.9 mm

EAS00284


CHECKING THE CLUTCH HOUSING

1. Check:

- clutch housing dogs
Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE:

Pitting on the clutch housing dogs will cause erratic clutch operation.



I1411301

EAS00285


CHECKING THE CLUTCH BOSS

1. Check:


- clutch boss splines
Damage/pitting/wear → Replace the clutch boss.

NOTE:

Pitting on the clutch boss splines will cause erratic clutch operation.



I1410301



EAS00288

CHECKING THE CLUTCH PUSH RODS

1. Check:

- O-ring ①
- short clutch push rod ②
- long clutch push rod ③
- ball ④


Cracks/damage/wear → Replace the defective part(-s).

2. Measure:

- long clutch push rod bending limit
Out of specification → Replace the long clutch push rod.



Long clutch push rod bending limit
0.2 mm



EAS00298


INSTALLING THE CLUTCH

1. Install:

- clutch housing ①
- thrust washer ②
- clutch boss ③
- lock washer ④
- clutch boss nut ⑤

NOTE:

Make sure that the teeth on the lock washer are correctly aligned with the grooves on the clutch boss.



2. Tighten:

- clutch boss nut ①


70 Nm (7.0 m•kg)

NOTE:

While holding the clutch boss with the universal clutch holder ②, tighten the clutch boss nut.



Universal clutch holder
90890-04086



3. Bend the lock washer tab along a flat side of the nut.

4. Lubricate:

- friction plates ①
 - clutch plates ②
- (with the recommended lubricant)



Recommended lubricant
Engine oil




5. Install:

- friction plates
- clutch plates

NOTE:

First, install a friction plate and then alternate between a clutch plate and a friction plate.




6. Install:

- long clutch push rod
- ball

7. Install:

- short clutch push rod ①
- O-ring ② **New**
- push plate ③
- washer ④
- nut ⑤




8. Install:

- pressure plate ①
- clutch springs ②
- clutch spring bolts ③

6 Nm (0.6 m•kg)

NOTE:

Tighten the clutch spring bolts in stages and in a crisscross pattern.




9. Check:

- push lever position
Push lever mark (a) and crankcase mark (b)
not aligned → Correct.

NOTE:

Push the push lever in direction (c) and make sure that the marks are aligned.



10. Adjust:

- push lever position




- Loosen the locknut ①.
- Turn the adjusting screw ② in or out until the marks are aligned.
- Hold the adjusting screw to prevent it from moving and then tighten the locknut to specification.

**CAUTION:**

Do not overtighten the locknut since this will remove the free play between both push rods.



Push lever lock nut
8Nm (0.8m•kg)



11. Install:

- clutch cover ①



7 Nm (0.7 m•kg)

NOTE:

Tighten the clutch cover bolts in stages and in a crisscross pattern.


SHIFT SHAFT AND STOPPER LEVER

ENG




EAS00327


SHIFT SHAFT AND STOPPER LEVER



Order	Job/Part	Q'ty	Remarks
	Removing the shift shaft and stopper lever		Remove the parts in the order listed.
	Clutch		Refer to "CLUTCH".
	Shift pedal		Refer to "ENGINE".
1	Shift shaft	1	Refer to "INSTALLING THE SHIFT SHAFT "
2	Plate washer	1	
3	Torsion spring	1	
4	Stopper lever	1	
5	Plate washer	1	
6	Circlip	1	
7	Torsion spring	1	
8	Collar	1	
9	Tension spring	1	



Order	Job/Part	Q'ty	Remarks
10	Screw	1	Refer to "INSTALLING THE SEGMENT".
11	Segment	1	
12	Dowel pins (short length)	4	
13	Dowel pins (long length)	1	
			For installation, reverse the removal procedure.




EAS00328


CHECKING THE SHIFT SHAFT

1. Check:

- shift shaft ①
 - shift lever ②
- Bends/damage/wear → Replace.



- shift lever spring
- Damage/wear → Replace.




EAS00330

CHECKING THE STOPPER LEVER

1. Check:

- stopper lever
- Bends/damage → Replace.
Roller turns roughly → Replace the stopper lever.




INSTALLING THE SEGMENT

1. Install:

- segment ①
- dowel pin ② (long length)
- dowel pins ③ (short length)

NOTE:

Install the dowel pin ②(long length) into the hole beside the match mark (a) position.



2. Install:


- segment ①

NOTE:

Fit the dowel pin ② (long length) on the segment to the locating hole (a) on the shift cam and install the segment.




OIL PUMP




Order	Job/Part	Q'ty	Remarks
	Removing the oil pump		
	Clutch		Remove the parts in the order listed
1	Nut	1	Refer to "CLUTCH".
2	Lock washer	1	Refer to "REMOVING/INSTALLING THE PRIMARY DRIVE GEAR".
3	Primary drive gear	1	
4	Oil pump drive gear	1	
5	Oil pump cover	1	Refer to "INSTALLING/THE OIL PUMP".
6	Oil pump assembly	1	
7	Gasket (oil pump cover)	1	
			For installation, reverse the removal procedure.



EAS00360




Order	Job/Part	Q'ty	Remarks
	Disassembling the oil pump		Disassemble the parts in the order listed.
1	Oil pump housing	1	Refer to "ASSEMBLING THE OIL PUMP."
2	Dowel pin	1	
3	Oil pump driven gear	1	
4	Dowel pins	2	
5	Inner rotor	1	
6	Outer rotor	1	
7	Housing	1	
			For assembly, reverse the disassembly procedure.

**REMOVING THE PRIMARY DRIVE GEAR**

1. Straighten the lock washer tab.
2. Remove:
 - nut (primary drive gear) ①
 - lock washer ②
 - primary drive gear ③

NOTE:

Place a folded aluminium plate or copper washer **a** between the teeth of the balancer drive gear ④ and balancer driven gear ⑤.




EAS00364

CHECKING THE OIL PUMP

1. Check:
 - primary drive gear ①
 - oil pump driven gear ②
 - oil pump housing ③
 - oil pump housing cover ④

Cracks/damage/wear → Replace the defective part(-s).
 2. Measure:
 - inner-rotor-to-outer-rotor-tip clearance **A**
 - outer-rotor-to-oil-pump-housing clearance **B**
 - oil-pump-housing-to-inner-rotor-and-outer-rotor clearance **C**

Out of specification → Replace the oil pump.
- ① Inner rotor
② Outer rotor
③ Oil pump housing

**Inner-rotor-to-outer-rotor-tip clearance**

0.03 ~ 0.09 mm
<Limit 0.14 mm>

Outer-rotor-to-oil-pump-housing clearance

0.10 ~ 0.15 mm
<Limit 0.35 mm>

Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance

0.03 ~ 0.09 mm
<Limit 0.14 mm>

3. Check:
 - oil pump operation

Unsmooth → Repeat steps (1) and (2) or replace the defective part(-s).




EAS411701

ASSEMBLING THE OIL PUMP**1. Lubricate:**

- inner rotor
- outer rotor
- oil pump shaft
(with the recommended lubricant)



Recommended lubricant
Engine oil


**2. Install:**

- oil pump shaft ①
(to the oil pump cover ②)
- pin ③
- inner rotor ④
- outer rotor ⑤
- pin ⑥
- oil pump housing ⑦
- screw ⑧

7 Nm (0.7 m•kg)

NOTE:

When installing the inner rotor, align the pin ③ in the oil pump shaft with the groove ① on the inner rotor ④.

**3. Check:**

- oil pump operation
Refer to "CHECKING THE OIL PUMP".

EAS00376


INSTALLING THE OIL PUMP**1. Install:**


- oil pump ①
- oil pump drive gear ②

7 Nm (0.7 m•kg)

CAUTION:

After tightening the bolts, make sure that the oil pump turns smoothly.





EAS00302

INSTALLING THE PRIMARY DRIVE GEAR**1. Install:**

- primary drive gear ①
- lock washer ② **New**
- primary drive gear nut ③


50 Nm (5.0 m•kg)**NOTE:**

- Place a folded aluminum plate ① or copper washer between the teeth of the balancer drive gear ④ and the balancer driven gear ⑤ in order to lock them.
- Do not damage the balancer drive and balancer driven gear's teeth.


-
- 2. Bend the lock washer tab along a flat side of the nut.**



BALANCER GEAR



Order	Job/Part	Q'ty	Remarks
	Removing the balancer gear		
	Clutch		Remove the parts in the order listed.
	Primary drive gear		Refer to "CLUTCH".
1	Nut/Lock washer	1/1	Refer to "OIL PUMP".
2	Balancer driven gear	1	Refer to "REMOVING/INSTALLING THE BALANCER DRIVEN GEAR".
3	Woodruff key	1	
4	Claw washer	1	
5	Balancer drive gear	1	
6	Buffer boss	1	Refer to "ASSEMBLING THE BALANCER DRIVE GEAR ASSEMBLY".
7	Compression spring	6	
8	Dowel pins	3	
9	Woodruff key	1	
10	Plate washer	1	
			For installation, reverse the removal procedure.




SR*****

REMOVING THE BALANCER DRIVEN GEAR

1. Straighten the lock washer tab.
2. Remove:
 - nut (balancer driven gear) ①
 - lock washer ②
 - balancer driven gear ③

NOTE:


Place a folded aluminium plate or copper washer (a) between the teeth of the balancer drive gear ④ and balancer driven gear ③.



SR*****

CHECKING THE BALANCER DRIVE GEAR

1. Inspect:
 - balancer drive gear ①
 - buffer boss ②
 - compression spring ③
 - dowel pins ④
- Wear/Pitting/Scratches → Replace.




SR*****

ASSEMBLING THE BALANCER DRIVE GEAR

1. Assembly:
 - dowel pins ①
 - compression springs ②

NOTE:



Install the dowel pins and compression springs alternately as shown as.



2. Install:
 - buffer boss ①

NOTE:

Align the punched mark (a) on the buffer boss with the one on the balancer drive gear.



SR*****

INSTALLING THE BALANCER DRIVEN GEAR

1. Install:

- balancer driven gear ①

NOTE:

Install the balancer driven gear, then mesh the balancer driven gear match mark (a) and balancer drive gear assembly match mark (b).

2. Install:

- lock washer ① **New**
- nut (balancer drive gear) ②

50 Nm (5.0 m•kg)


NOTE:

- Place a folded aluminium plate or copper washer (a) between the teeth of the balancer drive gear ③ and balancer driven gear ④.

3. Bend the lock washer tab, after tighten the nut flats.



STARTER CLUTCH AND GENERATOR GENERATOR COVER




Order	Job/Part	Q'ty	Remarks
	Removing the generator cover Drain the engine oil		Remove the parts in the order listed. Refer to "CHANGING THE ENGINE OIL" in CHAPTER 3.
	Side cover		Refer to "SEAT FUEL TANK AND SIDE COVER" in CHAPTER 3.
1	Generator lead couplers	1	
2	Generator cover	1	
3	Gasket	1	
4	Dowel pins	2	
			For installation, reverse the removal procedure.



EAS00341

STATOR COIL



Order	Job/Part	Q'ty	Remarks
	Removing the stator coil		
1	Clamp (stator coil)	1	Remove the parts in the order listed.
2	Clamp (pickup coil)	1	
3	Pickup coil	1	
4	Stator coil	1	
			For installation, reverse the removal procedure.


STARTER CLUTCH AND GENERATOR

ENG




EAS00343

STARTER CLUTCH AND GENERATOR ROTOR



Order	Job/Part	Q'ty	Remarks
	Removing the starter clutch and generator rotor		Remove the parts in the order listed.
1	Generator rotor	1	Refer to "REMOVING/INSTALLING THE GENERATOR ROTOR".
2	Idle shaft/collar	1	
3	Starter idle gear	1	
4	Woodruff key	1	
5	Starter wheel gear	1	
6	Shim	1	Refer to "INSTALLING THE STARTER CLUTCH".
7	Dowel pins (Inner)	3	
8	Spring caps	3	
9	Compression springs	3	
10	Dowel pins (outer)	3	
11	Starter clutch	1	For installation, reverse the removal procedure.




REMOVING THE GENERATOR ROTOR

1. Remove:
 - bolt ① (magneto)
 - plain washer ②

NOTE:

- Loosen the bolt (generator rotor) ① while holding the rotor with a sheave holder ③.
- Do not allow the sheave holder to touch the projection on the rotor.



Sheave holder:
90890-01701


2. Remove:
 - generator rotor ①
 - woodruff key

NOTE:

Remove the rotor using sheave holder ②, rotor puller ③ and rotor puller attachment ④.



Rotor puller:
90890-01080
Rotor puller attachment:
90890-04052



EAS00348

CHECKING THE STARTER CLUTCH


1. Check:
 - starter clutch idle gear ①
 - starter clutch drive gear ②
 - starter clutch gear ③

Burrs/chips/roughness/wear → Replace the defective part(-s).

2. Check:
 - starter clutch operation



- a. Hold the starter clutch.




b. When turning the starter clutch gear clockwise (a), the starter clutch and the starter clutch gear should engage.

If the starter clutch gear and starter clutch do not engage, the starter clutch is faulty and must be replaced.

c. When turning the starter clutch gear counter-clockwise (b), it should turn freely.


If the starter clutch gear does not turn freely, the starter clutch is faulty and must be replaced.



3. Inspect:

- dowel pins (1)
- compression springs (2)
- spring caps (3)


Wear/Damage → Replace.



4. Inspect:

- starter wheel gear (contacting surface)

Pitting/Wear/Damage → Replace.




INSTALLING THE STARTER CLUTCH

1. Install:

- starter clutch assembly (1)


30 Nm (3.0 m•kg)

2. Unloosen the starter clutch assembly by using the center punch.



3. Install:


- compression springs (1)
- spring caps (2)
- dowel pins (3)



INSTALLING THE GENERATOR ROTOR

1. Install:

- shim (1)
- starter wheel gear (2)
- woodruff key (3)




2. Install:

- generator rotor (1)

NOTE:

- Clean the tapered portion of the crankshaft and the rotor hub.
- When installing the rotor, make sure the woodruff key is properly seated in the key way of the crankshaft and turning the starter wheel gear (2) clockwise.



3. Tighten:

- generator rotor (1)

50 Nm (5.0 m•kg)

NOTE:


Tighten the bolt while holding the generator rotor with the sheave holder (2).




Sheave holder:
90890-01701



CRANKSHAFT
CRANKCASE




Order	Job/Part	Q'ty	Remarks
	Separation the crankcase		
	Engine		Remove the parts in the order listed.
	Cylinder head		Refer to "ENGINE".
	Cylinder and piston		Refer to "CYLINDER HEAD".
	Clutch		Refer to "CYLINDER AND PISTON".
	Primary drive gear/oil pump		Refer to "CLUTCH".
	Balancer weight drive gear		Refer to "OIL PUMP".
	Shift shaft and segment		Refer to "BALANCER DRIVE GEAR".
	Generator/starter clutch		Refer to "SHIFT SHAFT".
1	Timing chain guide (intake)	1	Refer to "STARTER CLUTCH AND GENERATOR".




Order	Job/Part	Q'ty	Remarks
2	Timing chain	1	Refer to "DISASSEMBLING/ASSEMBLING THE CRANKCASE". For installation, reverse the removal procedure.
3	Crankcase	1	
4	Dowel pins	2	



CRANKSHAFT AND BALANCER WEIGHT



Order	Job/Part	Q'ty	Remarks
	Removing the crankshaft and balancer weight		Remove the parts in the order listed.
1	Balancer weight	1	Refer to "INSTALLING THE CRANK-SHAFT".
2	Crankshaft assembly	1	
3	Dowel pin	1	Refer to "REMOVING/INSTALLING THE PLUNGER SEAL".
4	Plunger seal	1	
5	Compression spring	1	
6	Bearings (balancer weight)	2	
7	Bearing (crankshaft right)		
		1	For installation, reverse the removal procedure.



EAS00386


DISASSEMBLING THE CRANKCASE

1. Remove:

- crankcase bolts

NOTE:

- Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.
- Loosen the bolts in decreasing numerical order (refer to the numbers in the illustration).
- The numbers embossed on the crankcase indicate the crankcase tightening sequence.



2. Remove:


- right crankcase

NOTE:

Set the left crankcase half under then put in the flat head screw driver to the separating slit (a).

CAUTION:

- First check that the shift drum segment's teeth and the drive axle circlip are properly positioned, then remove the right crankcase.
- Do not damage the crankcase mating surfaces.



REMOVING THE PLUNGER SEAL

1. Remove:

- Dowel pin ①
- Plunger seal ②
- Compression spring ③

NOTE:

Remove the plunger seal and compression spring, push the plunger seal lightly and remove the dowel pin.



EAS00394


CHECKING THE CRANKSHAFT AND CONNECTING ROD

1. Measure:

- crankshaft runout
Out of specification → Replace the crankshaft, bearing or both.

NOTE:

Turn the crankshaft slowly.




Crankshaft runout
Less than 0.03 mm

2. Measure:

- big end axial clearance
Out of specification → Replace the big end bearing, crankshaft pin, or connecting rod.



Big end axial clearance
0.35 ~ 0.65 mm
Limit 1.0 mm




3. Measure:

- crankshaft width
Out of specification → Replace the crankshaft.




Crankshaft width
55.95 ~ 56.00 mm




4. Check:

- crankshaft sprocket ①
Damage/wear → Replace the crankshaft.
- bearing ②
Cracks/damage/wear → Replace the crankshaft.



5. Check:

- crankshaft journal
Scratches/wear → Replace the crankshaft.
- crankshaft journal oil passage
Obstruction → Blow out with compressed air.





EAS00401

CHECKING THE BEARINGS AND OIL SEALS

1. Check:

- bearings


Clean and lubricate the bearings, then rotate the inner race with your finger.

Rough movement → Replace.


2. Check:

- oil seals


Damage/wear → Replace.



I2510204



I2560103



EAS00207

CHECKING THE TIMING CHAIN, CAM-SHAFT SPROCKET, AND TIMING CHAIN GUIDES

1. Check:

- timing chain

Damage/stiffness → Replace the timing chain and camshaft sprocket as a set.

2. Check:

- camshaft sprocket

More than 1/4 tooth (a) wear → Replace the camshaft sprocket and the timing chain as a set.

(a) 1/4 tooth

(b) Correct

(1) Timing chain roller

(2) Camshaft sprocket

3. Check:

- timing chain guide (exhaust side)

- timing chain guide (intake side)

- timing chain guide (top side)

Damage/wear → Replace the defective part(-s).

SR*****

INSTALLING THE PLUNGER SEAL


1. Install:

- Compression spring (1)

- Plunger seal (2)

- Dowel pin (3)

2. Check the plunger seal smooth operation pushing the plunger seal by your finger.



EAS00408

INSTALLING THE CRANKSHAFT

1. Install:

- crankshaft assembly ①
- balancer weight assembly ②

CAUTION:

To avoid scratching the crankshaft and to ease the installation procedure, apply grease onto the oil seal lips and apply engine oil onto each bearing.

EAS00418

ASSEMBLING THE CRANKCASE


1. Thoroughly clean all the gasket mating surfaces and crankcase mating surfaces.
2. Apply:
 - sealant
(onto the crankcase mating surfaces)



Yamaha bond No. 1215
90890-85505

NOTE:

Do not allow any sealant to come into contact with the oil gallery (a).



3. Install:

- dowel pins
- right crankcase

4. Tighten:


- crankcase right half



7 Nm (0.7 m•kg)

NOTE:


Tighten the screws in decreasing numerical order (see numbers on the illustration).





TRANSMISSION


TRANSMISSION, SHIFT DRUM ASSEMBLY AND SHIFT FORKS




Order	Job/Part	Q'ty	Remarks
	Removing the transmission, shift drum assembly and shift forks		
	Crankcase separating		Remove the parts in the order listed.
			Refer to "CRANKCASE AND CRANKSHAFT".
1	Shift fork guide bar 2 (short length)	1	Refer to "INSTALLING THE TRANSMISSION, SHIFT FORK AND SHIFT DRUM ASSEMBLY".
2	Shift fork guide bar 1 (long length)	1	
3	Shift cam	1	
4	Shift fork 1 "C" (center)	1	
5	Shift fork 2 "R" (right)	1	
6	Shift fork 3 "L" (left)	1	
7	Main axle assembly	1	
8	Plate washer	1	Refer to "REMOVING THE TRANSMISSION".
9	Drive axle assembly	1	
10	Plate washer	1	For installation, reverse the removal procedure.



DRIVE AXLE AND MAIN AXLE



Order	Job/Part	Q'ty	Remarks
	Disassembling the drive axle and main axle		Disassemble the parts in the order listed.
①	Second wheel gear	1	
②	First wheel gear	1	
③	Fifth wheel gear	1	
④	Circlip/washer	1/1	
⑤	Third wheel gear	1	
⑥	Forth wheel gear	1	
⑦	Drive axle	1	
⑧	Second pinion gear	1	
⑨	Forth pinion gear	1	
⑩	Third pinion gear	1	
⑪	Circlip/washer	1/1	
⑫	Fifth pinion gear gear	1	
⑬	Main axle	1	
			For assembly, reverse the removal procedure.




EAS00420

REMOVING THE TRANSMISSION

1. Remove:

- Drive axle assembly ①
 - Main axle assembly ②
- Remove them at same the time.



EAS00421

CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks and related components.

1. Check:


- shift fork cam follower ①
 - shift fork pawl ②
- Bends/damage/scoring/wear → Replace the shift fork.

2. Check:


- shift fork guide bar
- Roll the shift fork guide bar on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent shift fork guide bar.




I1520401



I1520101

3. Check:

- shift fork movement
(on the shift fork guide bar)
- Rough movement → Replace the shift forks and shift fork guide bar as a set.




EAS00422

CHECKING THE SHIFT DRUM ASSEMBLY

1. Check:

- shift drum grooves
Damage/scratches/wear → Replace the shift drum.
- shift drum segment
Damage/wear → Replace.
- shift drum bearing
Damage/pitting → Replace.




EAS00424

CHECKING THE TRANSMISSION**1. Measure:**

- main axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the main axle.




Main axle runout limit
0.08 mm

**2. Measure:**


- drive axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the drive axle.



Drive axle runout limit
0.08 mm

**3. Check:**

- transmission gears
Blue discoloration/pitting/wear → Replace the defective gear(-s).




- transmission gear dogs
Cracks/damage/rounded edges → Replace the defective gear(-s).

4. Check:

- transmission gear engagement
(each pinion gear to its respective wheel gear)
Incorrect → Reassemble the transmission axle assemblies.

NOTE:


When reassembling the main axle, press the 2nd pinion gear ① onto it ② as shown.

**5. Check:**

- transmission gear movement
Rough movement → Replace the defective part(-s).

6. Check:

- circlips
Damage/bends/looseness → Replace.




EAS00426

INSTALLING THE TRANSMISSION, SHIFT FORKS AND SHIFT DRUM ASSEMBLY**1. Install:**

- shift fork 3 "L" (left) ①
(face the "L" side for the clutch side.)
- shift fork 2 "R" (right) ②
(face the "R" side for the clutch side.)
- shift fork 1 "C" (center) ③
(face the "C" side for the magneto side.)
- shift fork guide bar 1 ④ (long)
- shift fork guide bar 2 ⑤ (short)

NOTE:

Install the shift forks with the embossed mark to the right and in sequence (R, C, L) beginning from the right.


**2. Check:**

- shift cam operation
Unsmoothy operation → Repair.

NOTE:

Check the transmission and shift forks for smooth operation by turning the shift cam with your hand.





CARB

5

CHAPTER 5.

CARBURETOR


CARBURETOR	5-1
CHECKING THE CARBURETOR	5-4
ASSEMBLING THE CARBURETOR	5-5
INSTALLING THE CARBURETOR	5-7
MEASURING AND ADJUSTING THE FUEL LEVEL	5-7
CHECKING THE FUEL COCK	5-8
CHECKING THE FUEL COCK OPERATION	5-8



EAS00480

CARBURETOR


CARBURETOR




Order	Job/Part	Q'ty	Remarks
	Removing the carburetor		Remove the parts in order listed.
	Side cover		Refer to "SEAT, FUEL TANK AND SIDE COVER" in CHAPTER 3.
	Seat		
	Fuel tank		
	Heater unit lead		NOTE: _____ Disconnect the cable from wireharness.
1	Carburetor joint clamp screw	1	NOTE: _____
2	Air filter joint clamp screw	1	Loosen.
3	Carburetor assembly	1	
4	Carburetor top	1	
			For installation, reverse the removal procedure.



EAS00483




Order	Job/Part	Q'ty	Remarks
	Disassembly the carburetor		Disassemble the parts in the order listed.
①	Throttle cable	1	
②	Throttle valve assembly	1	
③	Throttle valve spring	1	
④	Mixing chamber top/O-ring	1/1	
⑤	Drain screw assembly	1	
⑥	Float chamber	1	
⑦	Gasket (float chamber)	1	
⑧	Float pin/float	1/1	Refer to "ASSEMBLYING THE CARBURETOR".
⑨	Needle valve assembly	1	
⑩	Main jet	1	
⑪	Main nozzle/O-ring	1/1	




Order	Job/Part	Q'ty	Remarks
⑫	Pilot screw assembly	1	Refer to "ASSEMBLING THE CARBURETOR".
⑬	Pilot jet	1	
⑭	Throttle stop screw assembly	1	
⑮	Starter plunger assembly	1	
⑯	Screw/gasket	1/1	For assembly, reverse the disassembly procedure.
⑰	Heater unit/washer	1/1	

CARBURETOR


CARB



8. Check:
- piston valve movement
Insert the piston valve into the carburetor body and move it up and down.
Tightness → Replace the piston valve.



9. Check:
- starter plunger ①
 - starter plunger spring ②
Bends/cracks/damage → Replace.




10. Check:
- hose joints
Cracks/damage → Replace.
11. Check:
- fuel hoses ①
Cracks/damage/wear → Replace.
Obstruction → Clean.
Blow out the hoses with compressed air.

EAS00487


ASSEMBLING THE CARBURETOR

CAUTION:


- Before assembling the carburetor, wash all of the parts in a petroleum-based solvent.
- Always use a new gasket.



1. Install:
- main nozzle ①
 - main jet ②
 - pilot jet ③




2. Install:
- needle valve seat ①




3. Install:
- float ①
 - needle valve
 - float pin ②


NOTE: _____
Install the float pin from the side opposite the arrow.



4. Install:
- float chamber ①
 - pilot screw ②



5. Install:
- starter plunger kit ①



CHAS

6

CHAPTER 6. CHASSIS

FRONT WHEEL AND BRAKE DISC	6-1
REMOVING THE FRONT WHEEL	6-3
CHECKING THE FRONT WHEEL	6-3
CHECKING THE BRAKE DISC	6-6
INSTALLING THE FRONT WHEEL	6-7
ADJUSTING THE FRONT WHEEL STATIC BALANCE	6-8
 REAR WHEEL AND REAR BRAKE	6-10
REAR WHEEL	6-10
REAR BRAKE AND REAR WHEEL SPROCKET	6-12
REMOVING THE REAR WHEEL	6-15
CHECKING THE REAR WHEEL	6-15
CHECKING AND REPLACING THE REAR WHEEL SPROCKET ..	6-16
CHECKING THE BRAKE	6-16
ASSEMBLING THE BRAKE SHOE PLATE	6-17
INSTALLING THE REAR WHEEL	6-18
ADJUSTING THE REAR WHEEL STATIC BALANCE	6-18
 FRONT BRAKE	6-19
FRONT BRAKE PADS	6-19
REPLACING THE FRONT BRAKE PADS	6-20
FRONT BRAKE MASTER CYLINDER	6-23
DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER ...	6-25
CHECKING THE FRONT BRAKE MASTER CYLINDER	6-25
ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER	6-26
FRONT BRAKE CALIPER	6-28
DISASSEMBLING THE FRONT BRAKE CALIPER	6-30
CHECKING THE FRONT BRAKE CALIPER	6-30
ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPER	6-31
 FRONT FORK	6-34
REMOVING THE FRONT FORK LEGS	6-36
DISASSEMBLING THE FRONT FORK LEGS	6-36
CHECKING THE FRONT FORK LEGS	6-37
ASSEMBLING THE FRONT FORK LEGS	6-38
INSTALLING THE FRONT FORK LEGS	6-41
 HANDLEBAR	6-42
REMOVING THE HANDLEBAR	6-44
CHECKING THE HANDLEBAR	6-44
INSTALLING THE HANDLEBAR	6-45
 STEERING HEAD	6-47

REMOVING THE LOWER BRACKET	6-49
CHECKING THE STEERING HEAD	6-49
INSTALLING THE STEERING HEAD	6-50

REAR SHOCK ABSORBER AND SWINGARM	6-51
HANDLING THE REAR SHOCK ABSORBER	6-52
DISPOSING OF A REAR SHOCK ABSORBER	6-52
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY	6-53
REMOVING THE DRIVE CHAIN	6-53
REMOVING THE SWINGARM	6-54
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	6-55
CHECKING THE SWINGARM	6-55
CHECKING THE DRIVE CHAIN	6-56
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	6-57
INSTALLING THE SWINGARM	6-58
INSTALLING THE DRIVE CHAIN	6-58




EAS00512


CHASSIS



FRONT WHEEL AND BRAKE DISC



Order	Job/Part	Q'ty	Remarks
	Removing the front wheel and brake disc		Remove the parts in the order listed. NOTE: _____ Place the motorcycle on a suitable stand so that the front wheel is elevated.
1	Speedometer cable	1	Refer to "REMOVING/INSTALLING THE FRONT WHEEL"
2	Wheel axle	1	
3	Front wheel assembly	1	
4	Collar	1	
5	Meter gear unit assembly	1	
6	Brake disc	1	For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the front wheel		Disassemble the parts in the order listed.
①	Oil seal	1	Refer to "ASSEMBLYNG/ DISASSEMBLING THE FRONT WHEEL".
②	Bearing	1	
③	Spacer	1	
④	Spacer flange	1	
⑤	Bearing	1	
			For assembly, reverse the disassembly procedure.



EAS00519

REMOVING THE FRONT WHEEL


1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the front wheel is elevated.



2. Remove:

- speedometer cable ①
- brake caliper ②
- wheel axle ③

NOTE:


Do not squeeze the brake lever when removing the brake caliper.

3. Elevate:

- front wheel

NOTE:

Place the motorcycle on a suitable stand so that the front wheel is elevated.



EAS00526

CHECKING THE FRONT WHEEL

1. Check:

- wheel axle
Roll the wheel axle on a flat surface.
Bends → Replace.

⚠ WARNING


Do not attempt to straighten a bent wheel axle.

2. Check:

- tire
- front wheel
Damage/wear → Replace.
Refer to "CHECKING THE TIRES" and "CHECKING THE WHEELS" in chapter 3.

FRONT WHEEL AND BRAKE DISC


CHAS



3. Check:
 - spokes
 - Bends/damage → Replace.
 - Loose → Tighten.
 - Tap the spokes with a screwdriver.

NOTE:

A tight spoke will emit a clear, ringing tone, a loose spoke will sound flat.




4. Tighten:
 - spokes

2 Nm (0.2 m•kg)

NOTE:

After tightening the spokes, measure the front wheel runout.



5. Measure:
 - front wheel radial runout (a)
 - front wheel lateral runout (b)
 - Over the specified limits → Replace.




Front wheel radial runout limit
2 mm
Front wheel lateral runout limit
2 mm


6. Check:
 - collars
 - Damage/wear → Replace.
 - Tire valve stem locknut

1.5 Nm (0.15 m•kg)

⚠ WARNING


- After mounting a new tire, ride conservatively for a while to become accustomed to the “feel” of the new tire and to allow the tire to seat itself properly in the rim. Failure to do so could lead to an accident with possible injury to the rider or damage to the motorcycle.
- After a tire has been repaired or replaced, be sure to tighten the tire valve stem locknut ① to specification.





7. Check:

- wheel bearings
Front wheel turns roughly or is loose → Replace the wheel bearings.
- oil seals
Damage/wear → Replace.



8. Replace:


- wheel bearings (New)
- oil seals (New)




- Clean the outside of the front wheel hub.
- Remove the oil seals (1) with a flat-head screwdriver.

NOTE:

To prevent damaging the wheel, place a rag (2) between the screwdriver and the wheel surface.



- Remove the wheel bearings (1) with a general bearing puller (2).



- Install the new wheel bearings and oil seals in the reverse order of disassembly.


CAUTION:

Do not contact the wheel bearing center race (1) or balls (2). Contact should be made only with the outer race (3).

NOTE:

Use a socket (4) that matches the diameter of the wheel bearing outer race and oil seal.





EAS00527


CHECKING THE BRAKE DISC

1. Check:
 - brake disc
Damage/galling → Replace.
2. Measure:
 - brake disc deflection ①
Out of specification → Correct the brake disc deflection or replace the brake disc.



Brake disc deflection limit (maximum)
0.15 mm

- a. Place the motorcycle on a suitable stand so that the front wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.
- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 2 ~ 3 mm below the edge of the brake disc.



3. Measure:
 - brake disc thickness
Measure the brake disc thickness at a few different locations.
Out of specification → Replace.



Brake disc thickness limit (minimum)
3 mm

4. Adjust:
 - brake disc deflection

- a. Remove the brake disc.
- b. Rotate the brake disc by one bolt hole.
- c. Install the brake disc.

NOTE:

Tighten the brake disc bolts in stages and in a crisscross pattern.



Brake disc bolt
13 Nm (1.3 m•kg)
LOCTITE®



- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.



EAS00542

INSTALLING THE FRONT WHEEL

1. Lubricate:

- wheel axle
- wheel bearings
- oil seal lips
- speedometer drive gear
- speedometer driven gear




Recommended lubricant
Lithium soap base grease

2. Install:

- speedometer gear unit ①

NOTE:

Make sure that the speedometer gear unit and the wheel hub are installed with the three projections ① meshed into the three slots ② respectively.




3. Install:

- front wheel

NOTE:

Make sure that the slot ① in the speedometer gear unit fits over the stopper ② on the outer tube.



4. Tighten:

- wheel axle
- brake caliper bolts

	90 Nm (9.0 m•kg)
	30 Nm (3.0 m•kg)

⚠ WARNING

Make sure that the brake hose is routed properly.

CAUTION:

Before tightening the wheel axle nut, push down hard on the handlebar several times and check if the front fork rebounds smoothly.




EAS00548

ADJUSTING THE FRONT WHEEL STATIC BALANCE

NOTE:

- After replacing the tire, wheel or both, the front wheel static balance should be adjusted.
- Adjust the front wheel static balance with the brake disc installed.




1. Remove:

- balancing weight(s) ①

NOTE:

Place the front wheel on a suitable balancing stand.




2. Find:

- front wheel's heavy spot



- Spin the front wheel.
- When the front wheel stops, put an "X₁" mark at the bottom of the wheel.



- Turn the front wheel 90° so that the "X₁" mark is positioned as shown.
- Release the front wheel.
- When the wheel stops, put an "X₂" mark at the bottom of the wheel.
- Repeat steps (b) through (d) several times until all the marks come to rest at the same spot.
- The spot where all the marks come to rest is the front wheel's heavy spot "X".



3. Adjust:


- front wheel static balance





- Install a balancing weight ① onto the rim exactly opposite the heavy spot "X".

NOTE:


Start with the lightest weight.






REAR WHEEL AND REAR BRAKE

REAR WHEEL




Order	Job/Part	Q'ty	Remarks
	Removing the rear wheel		Remove the parts in the order listed. NOTE: _____ Place the motorcycle on a suitable stand so that the rear wheel is elevated. _____
1	Adjuster	1	
2	Brake rod	1	
3	Pin	1	
4	Compression spring	1	
5	Chain case	1	
6	Axle nut/washer	1/1	
7	Chain pullers	2	
8	Wheel axle	1	Refer to "REMOVING/INSTALLING THE REAR WHEEL".




Order	Job/Part	Q'ty	Remarks
9	Rear wheel assembly	1	Refer to "REMOVING/INSTALLING THE REAR WHEEL." For installation, reverse the removal procedure.
10	Collar/O-ring	1/1	


REAR BRAKE AND REAR WHEEL SPROCKET



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake and rear wheel sprocket		Remove the parts in the order listed.
1	Shoe plate	1	Refer to "ASSEMBLYNG THE REAR WHEEL".
2	Nuts/washers (driven sprocket)	6/6	
3	Bolts	6	
4	Driven sprocket	1	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the rear wheel		
①	Bearing	1	Disassemble the parts in the order listed.
②	Collar	1	
③	Spacer	1	
④	Oil seal	1	
⑤	Bearing	1	
			For assembly, reverse the disassembly procedure.



Order	Job/Part	Q'ty	Remarks
①	Disassembling the brake shoe plate		
②	Brake shoe kit	2	Disassemble the parts in the order listed. Refer to "REMOVING THE REAR WHEEL/ASSEMBLYING THE BRAKE SHOE PLATE". For assembly, reverse the disassembly procedure.
③	Tension springs	2	
④	Camshaft lever	1	
⑤	Indicator plate	1	
	Camshaft	1	



EAS00563

REMOVING THE REAR WHEEL


1. Stand the motorcycle on a level surface.

! WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.




2. Remove:

- wheel axle ①
- rear wheel

NOTE:

Push the rear wheel forward and remove the drive chain from the rear wheel sprocket.



3. Remove:

- brake shoe plate

4. Remove:

- brake shoes ①
- brake camshaft lever ②

NOTE:

Mark the position on the brake camshaft lever where it is aligned with the punch mark on the brake camshaft.

EB701401

CHECKING THE REAR WHEEL

1. Check:

- wheel axle
 - rear wheel
 - wheel bearings
 - oil seals
- Refer to "FRONT WHEEL".

2. Check:


- tire
 - rear wheel
- Damage/wear → Replace.
Refer to "CHECKING THE TIRES" and "CHECKING THE WHEELS" in chapter 3.

3. Check:

- spokes
- Refer to "FRONT WHEEL".

4. Measure:

- rear wheel radial runout
 - rear wheel lateral runout
- Refer to "FRONT WHEEL".



I2560103

EAS00568

CHECKING AND REPLACING THE REAR WHEEL SPROCKET

1. Check:

- rear wheel sprocket

More than 1/4 tooth (a) wear → Replace the rear wheel sprocket.

Bent teeth → Replace the rear wheel sprocket.

(b) Correct

(1) Drive chain roller

(2) Rear wheel sprocket

2. Replace:

- rear wheel sprocket



a. Remove the self-locking nuts and the rear wheel sprocket.

b. Clean the rear wheel drive hub with a clean cloth, especially the surfaces that contact the sprocket.

c. Install the new rear wheel sprocket.



Rear wheel sprocket self-locking nut

35 Nm (3.5 m•kg)

NOTE:

Tighten the self-locking nuts in stages and in a crisscross pattern.



EAS00569

CHECKING THE BRAKE

The following procedure applies to all of the brake shoes.

1. Check:


- brake shoe lining

Glazed areas → Repair.

Sand the glazed areas with course sandpaper.

NOTE:

After sanding the glazed areas, clean the brake shoe with a cloth.



346-026



Brake shoe lining thickness limit (minimum)

2 mm



EAS00571

INSTALLING THE REAR WHEEL

1. Lubricate:

- wheel axle
- wheel bearings
- oil seal lips



Recommended lubricant
Lithium soap base grease

2. Adjust:

- drive chain slack



Drive chain slack
35 ~ 60 mm

Refer to “ADJUSTING THE DRIVE CHAIN SLACK” in chapter 3.

3. Tighten:

- wheel axle nut



90 Nm (9.0 m•kg)



WARNING

Make sure that the brake hose is routed properly.

EAS00575

ADJUSTING THE REAR WHEEL STATIC BALANCE


NOTE:

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and rear wheel drive hub installed.

1. Adjust:

- rear wheel static balance
- Refer to “FRONT WHEEL”.

FRONT BRAKE
FRONT BRAKE PADS



Order	Job/Part	Q'ty	Remarks
1	Removing the front brake pads		Remove the parts in the order listed.
2	Bolt (caliper support bolt)	1	Refer to "REPLACING THE FRONT BRAKE PADS".
3	Brake pads	2	
	Pad springs	1	
			For installation, reverse the removal procedure.



EAS00579

CAUTION:

Disc brake components rarely require disassembly.

Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.

First aid for brake fluid entering the eyes:



- Flush with water for 15 minutes and get immediate medical attention.

EAS00581

REPLACING THE FRONT BRAKE PADS

NOTE:

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.




1. Remove:
 - caliper support bolts ①
2. Remove:
 - brake caliper ②
3. Remove:
 - brake pads ①
 - brake pad spring ②

FRONT BRAKE

CHAS

7. Install:

- brake caliper
- brake pad bolt

**27 Nm (2.7 m•kg)**

8. Check:

- brake fluid level

Below the minimum level mark (a) → Add the recommended brake fluid to the proper level. Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.

9. Check:


- brake lever operation

Soft or spongy feeling → Bleed the brake system.


Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.








FRONT BRAKE MASTER CYLINDER



Order	Job/Part	Q'ty	Remarks
	Removing the front brake master cylinder		Remove the parts in the order listed.
1	Drain the brake fluid	1	
2	Rear view mirror (right)	1/1	
3	Brake lever/compression spring	1	
4	Brake switch	1	
5	Union bolt	1	
6	Copper washers	2	Refer to "DISASSEMBLING/ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER".
7	Brake hose	1	
8	Bracket (master cylinder)	1	
	Master cylinder	1	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the front brake master cylinder		Disassemble the parts in the order listed.
①	Rubber boots	1	
②	Circlip	1	
③	Master cylinder kit	1	
④	Spring	1	
			For assembly, reverse the removal procedure.



EAS00588

DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER

NOTE:

Before disassembling the front brake master cylinder, drain the brake fluid from the entire brake system.

1. Disconnect:

- brake switch ①

2. Remove:

- union bolt ①
- copper washers ②
- brake hose ③

NOTE:

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

EAS00590

CHECKING THE FRONT BRAKE MASTER CYLINDER

1. Check:


- brake master cylinder ①
Damage/scratches/wear → Replace.
- brake fluid delivery passages ②
(brake master cylinder body)
Obstruction → Blow out with compressed air.

2. Check:

- brake master cylinder kit ①
Damage/scratches/wear → Replace.

3. Check:

- brake master cylinder reservoir diaphragm
Damage/wear → Replace.



4. Check:

- brake hose ①
Cracks/damage/wear → Replace.

EAS00598

ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER

⚠ WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



**Recommended brake fluid
DOT 4**



1. Install:

- brake master cylinder ①

7 Nm (0.7 m•kg)

NOTE:

- Install the brake master cylinder holder with the “UP” mark ② facing up.
- First, tighten the upper bolt, then the lower bolt.



2. Install:

- copper washers ① **New**
- brake hose ②
- union bolt ③


26 Nm (2.6 m•kg)

⚠ WARNING

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to “CABLE ROUTING”.

CAUTION:

When installing the brake hose onto the master cylinder, make sure that the brake pipe ① touches the projection ② on the master cylinder.



**NOTE:**

Turn the handlebar to the left and to the right to make sure that the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.

3. Fill:

- brake master cylinder reservoir
(with the specified amount of the recommended brake fluid)



Recommended brake fluid
DOT 4

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

4. Bleed:


- brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

5. Check:


- brake fluid level
Below the minimum level mark (a) → Add the recommended brake fluid to the proper level. Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.

6. Check:


- brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.




FRONT BRAKE CALIPER



Order	Job/Part	Q'ty	Remarks
	Removing the front brake caliper		Remove the parts in the order listed.
1	Drain teh brake fluid	1	Refer to "DISASSEMBLING/ ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPER" .
2	Brake hose holder	1	
3	Union bolt	1	
4	Plain washer	1	
5	Brake hose	1	
6	Caliper support bolt	1	
	Caliper assembly	1	For installation, reverse the removal procedure.




Order	Job/Part	Q'ty	Remarks
	Disassembling the front brake cali- per		Disassemble the parts in the order listed.
①	Brake pad	2	Refer to "BRAKE PAD" section.
②	Caliper pistons	2	Refer to "DISASSEMBLING THE FRONT BRAKE CALIPER".
③	Dust seals	2	
④	Piston seals	2	
	Bleed screw/Cap	1	For assembly, reverse the disassembly procedure.



1. Check:
 - brake caliper pistons ①
Rust/scratches/wear → Replace the brake caliper.
 - brake caliper cylinders ②
Scratches/wear → Replace the brake caliper.
 - brake caliper body ③
Cracks/damage → Replace the brake caliper.
 - brake fluid delivery passages (brake caliper body)
Obstruction → Blow out with compressed air.

⚠ WARNING

Whenever a brake caliper is disassembled, replace the piston seals.




2. Check:
 - brake caliper bracket ①
Cracks/damage → Replace.

EAS00634

ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPER

⚠ WARNING


- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.



Recommended brake fluid
DOT 4

1. Install:
 - brake caliper ① (temporarily)
 - copper washers ② **New**
 - brake hose ③
 - union bolt ④

⚡ 26 Nm (2.6 m•kg)



⚠ WARNING

Proper brake hose routing is essential to insure safe motorcycle operation. Refer to "CABLE ROUTING".

CAUTION:

When installing the brake hose onto the brake caliper ①, make sure that the brake pipe ② touches the projection ③ on the brake caliper.

2. Remove:

- brake caliper

3. Install:

- brake pads
- brake pad springs
- brake caliper retaining bolt

27 Nm (2.7 m•kg)

- brake caliper bracket

30 Nm (3.0 m•kg)

- brake hose holder

Refer to "REPLACING THE BRAKE PADS".

4. Fill:

- brake master cylinder reservoir
(with the specified amount of the recommended brake fluid)




**Recommended brake fluid
DOT 4**

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

**CAUTION:**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.



5. Bleed:

- brake system

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.

6. Check:

- brake fluid level

Below the minimum level mark (a) → Add the recommended brake fluid to the proper level. Refer to "CHECKING THE BRAKE FLUID LEVEL" in chapter 3.


7. Check:

- brake lever operation


Soft or spongy feeling → Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.

FRONT FORK



Order	Job/Part	Q'ty	Remarks
	Removing the front fork		
	Front wheel		Remove the parts in the order listed. Refer to "FRONT WHEEL AND BRAKE DISC".
1	Brake hose holder	1	
2	Caliper	1	
3	Front fender	1	
4	Cap bolt/O-ring	1/1	
5	Bolt (upper bracket)	1	Refer to "REMOVING/INSTALLING THE FRONT FORK".
6	Bolts (under bracket)	2	NOTE: _____
7	Front fork assembly (left)	1	Loosen the bolt.
8	Front fork assembly (right)	1	_____
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the front fork		Disassemble the parts in the order listed.
①	Cap bolt/O-ring	1/1	NOTE: _____
②	Collar/washer	1/1	
③	Fork spring	1	Drain the fork oil.
④	Boot	1	Refer to "DISASSEMBLING/ ASSEMBLING THE FRONT FORK".
⑤	Retaining clip	1	
⑥	Oil seal	1	Refer to "ASSEMBLING THE FRONT FORK"
⑦	Damper rod bolt	1	
⑧	Inner tube assembly	1	
⑨	Oil seal	1	
⑩	Outer tube bushing	1	
⑪	Damper rod	1	
⑫	Rebound spring	1	
⑬	Outer tube	1	
			For assembly, reverse the disassembly procedure.



EAS00649

REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.


1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the front wheel is elevated.



2. Loosen:

- upper bracket pinch bolt ①
- cap bolt ②
- lower bracket pinch bolt ③

⚠ WARNING

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.

3. Remove:

- front fork leg

EAS00655

DISASSEMBLING THE FRONT FORK LEGS


The following procedure applies to both of the front fork legs.

1. Drain:

- fork oil

NOTE:

While stroking the inner tube several times, drain the fork oil.



2. Remove:


- boot ①
- oil seal clip ②
(with a flat-head screwdriver)

CAUTION:

Do not scratch the inner tube.

FRONT FORK

CHAS



3. Remove:
- damper rod bolt
 - copper washer

NOTE:

While holding the damper rod with the damper rod holder ① and T-handle ②, loosen the damper rod bolt.




Damper rod holder

90890-01294

T-handle

90890-01326

4. Remove:
- inner tube



EAS00657

CHECKING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.


1. Check:

- inner tube ①
- outer tube ②

Bends/damage/scratches → Replace.

⚠ WARNING

Do not attempt to straighten a bent inner tube as this may dangerously weaken it.



2. Measure:


- spring free length (a)

Over the specified limit → Replace.



Spring free length limit

338 mm



3. Check:

- damper rod ①

Damage/wear → Replace.

Obstruction → Blow out all of the oil passages with compressed air.



CAUTION:

- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.

4. Check:

- cap bolt O-ring
Damage/wear → Replace.

EAS00659

ASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

⚠ WARNING

- Make sure that the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

NOTE:


- When assembling the front fork leg, be sure to replace the following parts:
-outer tube bushing
-oil seal
- Before assembling the front fork leg, make sure that all of the components are clean.

1. Install:

- damper rod ①
- inner tube ②

CAUTION:

Allow the damper rod to slide slowly down the inner tube until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.





2. Lubricate:

- inner tube's outer surface



Recommended lubricant
Fork oil 10W or equivalent

3. Tighten:


- damper rod bolt



27 Nm (2.7 m•kg)

NOTE:

While holding the damper rod with the damper rod holder ① and T-handle ②, tighten the damper rod bolt.




Damper rod holder
90890-01294
T-handle
90890-01326

4. Install:

- outer tube bushing ①
(with the fork seal driver weight and adapter)



Fork seal driver weight
90890-01367
Adapter
90890-01368



5. Install:



- oil seal ①
(with the fork seal driver weight and adapter)


CAUTION:

Make sure that the numbered side of the oil seal faces up.

NOTE:

- Before installing the oil seal, apply lithium soap base grease onto its lips.
- Apply fork oil onto the outer surface of the inner tube.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag ② to protect the oil seal during installation.







6. Install:
- oil seal clip ①

NOTE:

Adjust the oil seal clip so that it fits into the outer tube's groove.



7. Install:
- boot ①




8. Fill:
- front fork leg
(with the specified amount of the recommended fork oil)



Quantity (each front fork leg)
0.243 L
Yamaha fork and shock oil
10W or equivalent.




Front fork leg oil level ① (from the top of the inner tube, with the inner tube fully compressed and without the fork spring)
135 mm



NOTE:



- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.



9. Install:
- spring ①
 - spring seat ②
 - spacer ③
 - cap bolt ④

NOTE:

- Before installing the cap bolt, apply grease onto O-ring.
- Temporarily tighten the cap bolt.



EAS00662

INSTALLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Install:

- front fork leg

Temporarily tighten the upper and lower bracket pinch bolts.

NOTE:

Make sure that the inner fork tube is flush with the top of the handlebar holder.

2. Tighten:

- lower bracket pinch bolt ①

30 Nm (3.0 m•kg)

- cap bolt ②

23 Nm (2.3 m•kg)

- upper bracket pinch bolt ③


23 Nm (2.3 m•kg)

WARNING


Make sure that the brake hoses are routed properly.





HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	Removing the handlebar		Remove the parts in the order listed.
1	Master cylinder bracket	1	Refer to "INSTALLING THE HANDLE-BAR".
2	Master cylinder	1	
3	Housing (throttle grip)	1	
4	Throttle grip assembly	1	
5	Handlebar switch (right)	1	
6	Clutch switch	1	
7	Clutch cable	1	



Order	Job/Part	Q'ty	Remarks
8	Handlebar switch (left)	1	Refer to "REMOVING THE HANDLEBAR" section.
9	Grip (left)	1	
10	Clutch lever	1	Refer to "INSTALLING THE HANDLEBAR" section. For installation, reverse the removal procedure.
11	Starter cable holder	1	
12	Upper holders	2	
13	Handlebar	1	



EAS00666

REMOVING THE HANDLEBAR

1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

2. Remove:
- throttle cable housing ①
 - throttle grip ②

3. Remove:
- handlebar grip (left) ①

NOTE:

Blow compressed air between the handlebar and the handlebar grip, and gradually push the grip off the handlebar.


EAS00668

CHECKING THE HANDLEBAR

1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.



2. Check:
- handlebar ①
Bends/cracks/damage → Replace.

⚠ WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.

3. Install:
- handlebar grip

- a. Apply a light coat of rubber adhesive onto the left end of the handlebar.
- b. Slide the handlebar grip over the left end of the handlebar.
- c. Wipe off any excess rubber adhesive with a clean rag.



⚠ WARNING

Do not touch the handlebar grip until the rubber adhesive has fully dried.





EB704700

INSTALLING THE HANDLEBAR

1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.



2. Install:

- handlebar ①
- upper handlebar holders ②

20 Nm (2.0 m•kg)

CAUTION:

- First, tighten the bolts on the front side of the handlebar holder, then on the rear side.
- Turn the handlebar all the way to the left and right. If there is any contact with the fuel tank, adjust the handlebar position.

NOTE:


- The upper handlebar holders should be installed with the arrows ① facing forward.

- ① large
- ② short

- Align the match marks ③ on the handlebar with the upper surface of the lower handlebar holders.

3. Install:

- throttle grip
- throttle cable housing
- throttle cable




4. Install:

- right handlebar switch ①

NOTE:

Align the pin ① on the handlebar switch with the hole ② in the handlebar.



5. Install:
- left handbar switch

NOTE:

Align the tab (a) on the plate with the slot (b) on the handbar switch/

6. Install:
- clutch cable
7. Connect:
- clutch switch coupler

NOTE:

Apply a thin coat of lithium soap base grease onto the end of the clutch cable.

8. Adjust:
- clutch cable free play
- Refer to "ADJUSTING THE CLUTCH CABLE FREE PLAY" in chapter 3.



Clutch cable free play (at the end of the clutch lever)
10 ~ 15 mm


9. Adjust:
- throttle cable free play
- Refer to "ADJUSTING THE THROTTLE CABLE FREE PLAY" in chapter 3.




Throttle cable free play (at the flange of the throttle grip)
3 ~ 5 mm



STEERING HEAD



Order	Job/Part	Q'ty	Remarks
	Removing the lower bracket		
	Front fork		Remove the parts in the order listed.
	Handlebar		Refer to "FRONT FORK".
	Headlight cover	1	Refer to "HANDLEBAR"
1	Headlight unit	1	
2	Flasher light assembly (left)	1	
3	Flasher light assembly (right)	1	
4	Meter cable/Meter lead	1	
5	Meter assembly	1/1	NOTE: _____
6	Headlight stay	1	Disconnect the connector.
7	Steering stem nut	2	
8	Handlebar crown	1	
9	Lock washer	1	
10	Upper ring nut	1	
11	Rubber washer	1	
12	Lower ring nut	1	Refer to "INSTALLING THE STEERING HEAD".
13	Ball race cover	1	
14	Lower bracket	1	



Order	Job/Part	Q'ty	Remarks
16	Ball race (upper)	1	Refer to "INSTALLING THE STEERING".
17	Ball	22	
18	Ball	19	
19	Ball race (center)	1	
20	Ball race (lower)	1	
			For installation, reverse the removal procedure.




EAS00679

REMOVING THE LOWER BRACKET

1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.



2. Remove:

- upper ring nut
- rubber washer
- lower ring nut ①

NOTE:

Hold the lower ring nut with the exhaust and steering nut wrench, then remove the upper ring nut with the ring nut wrench.



Exhaust and steering nut wrench ②
90897-01268

⚠ WARNING

Securely support the lower bracket so that there is no danger of it falling.

EAS00682

CHECKING THE STEERING HEAD

1. Wash:

- bearing balls
- bearing races



Recommended cleaning solvent
Kerosine

2. Check:



- bearing balls ①
- bearing races ②


Damage/pitting → Replace.

3. Replace:

- bearing balls
- bearing races

a. Remove the bearing races from the steering head pipe with a long rod ① and hammer.





- b. Remove the bearing race from the lower bracket with a floor chisel ② and hammer.
- c. Install a new dust seal and new bearing races.

CAUTION:

If the bearing race is not installed properly, the steering head pipe could be damaged.

NOTE:

- Always replace the bearing balls and bearing races as a set.
- Whenever the steering head is disassembled, replace the dust seal.

4. Check:

- upper bracket
- lower bracket
(along with the steering stem)
Bends/cracks/damage → Replace.

EAS00683


INSTALLING THE STEERING HEAD

1. Lubricate:

- upper bearing
- lower bearing
- bearing races



Recommended lubricant
Lithium soap base grease



2. Install:

- lower ring nut ①
- rubber washer
- upper ring nut ②
- lock washer ③

Refer to "INSPECTING THE STEERING HEAD" in chapter 3.

3. Install:

- upper bracket
- steering stem nut

NOTE:

Temporarily tighten the steering stem nut.


4. Install:

- front fork legs
Refer to "FRONT FORK".

NOTE:

Temporarily tighten the upper and lower bracket pinch bolts.

REAR SHOCK ABSORBER AND SWINGARM



Order	Job/Part	Q'ty	Remarks
	Rear shock absorber and swingarm removal		
	Rear wheel		Refer to "REAR WHEEL AND REAR BRAKE."
	Chain case		
1	Rear shock absorber	1	Refer to "REMOVING/INSTALLING THE REAR SHOCK ABSORBER"
2	Drive chain	1	Refer to "REMOVING/INSTALLING THE DRIVE CHAIN"
3	Nut	1	Refer to REMOVING/INSTALLING THE SWINGARM".
4	Pivot shaft	1	
5	Swingarm	1	
6	Cover (swingarm)	2	
7	Bush	2	
			For installation, reverse the removal procedure.



EAS00694

REMOVING THE REAR SHOCK ABSORBER ASSEMBLY


1. Stand the motorcycle on a level surface.

WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.




2. Remove:

- rear shock absorber assembly lower pin ①

NOTE:

While removing the rear shock absorber assembly lower pin, hold the swingarm so that it does not drop down.



3. Remove:

- rear shock absorber assembly upper bolt ①
- rear shock absorber assembly

NOTE:

Raise the swingarm and then remove the rear shock absorber assembly from between the swingarm and relay arm.

EAS00706

REMOVING THE DRIVE CHAIN


1. Stand the motorcycle on a level surface.

WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.



2. Remove:

- chain cover ②

3. Remove:

- master link clip (with interlocking slip-joint pliers)

4. Remove:

- master link plate ①
- master link ②

5. Remove:

- drive chain



EAS00703

REMOVING THE SWINGARM



1. Stand the motorcycle on a level surface.

⚠ WARNING

Securely support the motorcycle so that there is no danger of it falling over.

NOTE:

Place the motorcycle on a suitable stand so that the rear wheel is elevated.



2. Remove:

- rear shock absorber assembly lower pin ①

NOTE:

When removing the rear shock absorber assembly lower pin, hold the swingarm so that it does not drop down.

3. Check:

- swingarm side play [A]
- swingarm vertical movement [B]



- a. Check the tightening torque of the pivot shaft nut.



Pivot shaft nut
80 Nm (8.0 m•kg)


- b. Check the swingarm side play [A] by moving the swingarm from side to side.
- c. If the swingarm side play is out of specification, check the spacers, bearings, washers, and dust covers.



Swingarm side play (at the end of the swingarm)
1.0 mm

- d. Check the swingarm vertical movement [B] by moving the swingarm up and down.
If swingarm vertical movement is not smooth or if there is binding, check the spacers, bearings, washers, and dust covers.






EAS00696

CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

1. Check:

- rear shock absorber rod
Bends/damage → Replace the rear shock absorber assembly.
- rear shock absorber
Gas leaks/oil leaks → Replace the rear shock absorber assembly.
- spring
Damage/wear → Replace the rear shock absorber assembly.
- bushings
Damage/wear → Replace.
- dust seals
Damage/wear → Replace.
- bolts
Bends/damage/wear → Replace.




EAS00707

CHECKING THE SWINGARM

1. Check:

- swingarm
Bends/cracks/damage → Replace.



2. Check:

- pivot shaft
Roll the pivot shaft on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent pivot shaft.

3. Wash:


- pivot shaft
- dust covers
- spacer
- washers
- bearings



Recommended cleaning solvent
Kerosine

REAR SHOCK ABSORBER AND SWINGARM

CHAS



4. Check:


- drive chain rollers ①
Damage/wear → Replace the drive chain.
- drive chain side plates ②
Damage/wear → Replace the drive chain.
Cracks → Replace the drive chain and make sure that the battery breather hose is properly routed away from the drive chain and below the swingarm.

5. Lubricate:

- drive chain



Recommended lubricant
Engine oil or chain lubricant
suitable for non-O-ring chains



6. Check:

- drive sprocket
- rear wheel sprocket
More than 1/4 tooth (a) wear → Replace the drive chain sprockets as a set.
Bent teeth → Replace the drive chain sprockets as a set.

(b) Correct

① Drive chain roller

② Drive chain sprocket

EAS00697

INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

1. Lubricate:

- spacers
- bearings



Recommended lubricant
Molybdenum disulfide grease

2. Install:

- rear shock absorber assembly

56 Nm (5.6 m•kg)

NOTE:

When installing the rear shock absorber assembly, lift up the swingarm.



EAS00711

INSTALLING THE SWINGARM

1. Lubricate:
 - bearings
 - spacers
 - dust covers
 - pivot shaft



Recommended lubricant
Molybdenum disulfide grease

2. Install:
 - Swingarm



80 Nm (8.0 m•kg)

3. Install
 - rear shock absorber assembly
 - rear wheel



Refer to "INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY" and "REAR WHEEL".

4. Adjust:
 - drive chain slack

Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.



Drive chain slack
35 ~ 60 mm



343 004

EAS00714

INSTALLING THE DRIVE CHAIN

1. Lubricate:
 - drive chain
 - master link (New)



Recommended lubricant
Engine oil or chain lubricant
suitable for non-O-ring chains

2. Install:
 - master link ①
 - master link plate ②

3. Install:
 - master link clip ①

CAUTION:

- The closed end of the master link clip must face in the direction of drive chain rotation.
- Never install a new drive chain onto worn drive chain sprockets; this will dramatically shorten the drive chain's life.

4. Adjust:
 - drive chain slack


Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.



Drive chain slack
35 ~ 60 mm

**CAUTION:**

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.



ELEC

7

CHAPTER 7. ELECTRICAL


ELECTRICAL COMPONENTS	7-1
SWITCHES	7-2
CHECKING SWITCH CONTINUITY	7-2
SWITCH CONTINUITY INSPECTION	7-3
CHECKING THE BULBS AND BULB SOKETS	7-4
TYPES OF BULBS	7-4
CHECKING THE CONDITION OF THE BULBS	7-4
CHECKING THE CONDITION OF THE BULB SOCKETS	7-6
IGNITION SYSTEM	7-7
CIRCUIT DIAGRAM	7-7
TROUBLESHOOTING	7-8
ELECTRIC STARTING SYSTEM	7-12
CIRCUIT DIAGRAM	7-12
STARTING CIRCUIT CUTOFF SYSTEM OPERATION	7-13
TROUBLESHOOTING	7-14
STARTER MOTOR	7-17
CHARGING SYSTEM	7-20
CIRCUIT DIAGRAM	7-20
TROUBLESHOOTING	7-21
LIGHTING SYSTEM	7-23
CIRCUIT DIAGRAM	7-23
TROUBLESHOOTING	7-24
CHECKING THE LIGHTING SYSTEM	7-25
SIGNAL SYSTEM	7-28
CIRCUIT DIAGRAM	7-28
TROUBLESHOOTING	7-29
CHECKING THE SIGNALING SYSTEM	7-30






EAS00729

ELECTRICAL ELECTRICAL COMPONENTS

- | | | |
|------------------------|---------------------|---------------|
| ① Horn | ⑧ Neutral relay | ⑮ C.D.I. unit |
| ② Flasher relay | ⑨ Thermo switch | |
| ③ Main switch | ⑩ Sidestand switch | |
| ④ Fuse holder assembly | ⑪ Rear brake switch | |
| ⑤ Starter relay | ⑫ Neutral switch | |
| ⑥ Rectifier/Regulator | ⑬ Spark plug cap | |
| ⑦ Battery | ⑭ Ignition coil | |





EAS00730

SWITCHES

CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester
90890-03112

NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left. The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.

NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between blue/red and red when the switch is set to "P".

There is continuity between blue/red and blue, between brown/blue and red, and between blue/yellow and blue/black when the switch is set to "ON".



EAS00731


SWITCH CONTINUITY INSPECTION


Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to "CHECKING SWITCH CONTINUITY".

Damage/wear → Repair or replace the switch.

Improperly connected → Properly connect.

Incorrect continuity reading → Replace the switch.





EAS00732


CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.


Damage/wear → Repair or replace the bulb, bulb socket or both.

Improperly connected → Properly connect.

Incorrect continuity reading → Repair or replace the bulb, bulb socket or both.



I8410603



I8410604

TYPES OF BULBS

The bulbs used on this motorcycle are shown in the illustration on the left.

- Bulbs (A) and (B) are used for headlights and usually use a bulb holder which must be detached before removing the bulb. The majority of these bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulb (C) is used for turn signal and tail/brake lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs (D) and (E) are used for meter and indicator lights and can be removed from their respective socket by carefully pulling them out.

CHECKING THE CONDITION OF THE BULBS

The following procedure applies to all of the bulbs.


1. Remove:

- bulb



EAS00734

IGNITION SYSTEM CIRCUIT DIAGRAM





EAS00736

TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

Check:

1. spark plug
2. ignition spark gap
3. spark plug cap resistance
4. ignition coil
5. pickup coil resistance
6. source coil resistance
7. main switch
8. engine stop switch
9. sidestand switch
10. neutral relay
11. neutral switch
12. diode
13. wiring connection
(entire ignition system)

NOTE:

- Before troubleshooting, remove the following part(-s):
 - 1) side covers (left and right)
 - 2) seat
 - 3) fuel tank
- Troubleshoot with the following special tool(-s).



Ignition checker
90890-06754
Pocket tester
90890-03112

EAS06740

1. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.
Refer to "CHECKING THE SPARK PLUG" in CHAPTER 3.



Standard spark plug
DR8EA (NGK)
Spark plug gap
0.6 ~ 0.7 mm

- Is the spark plug in good condition, is it of the correct type, and its gap within specification?

↓ YES


↓ NO

Re-gap or replace the spark plug.

EAS00742

2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition checker ① as shown.
- ② Spark plug cap
- Turn the main switch to "ON".
- Measure the ignition spark gap (a).
- Check the spark by pushing the starter switch, and gradually increase the spark gap until a misfire occurs.



Min. ignition spark gap
6 mm

- Is there a spark and is the spark gap within specification?

↓ NO


↓ YES

The ignition system is OK.

EAS00744

3. Spark plug cap resistance

- Remove the spark plug cap.
- Connect the pocket tester ($\Omega \times 1k$) to the spark plug cap as shown.
- Measure the spark plug cap resistance.





Spark plug cap resistance
10 k Ω at 20°C

- Is the spark plug cap OK?

YES

NO

Replace the spark plug cap.



Secondary coil resistance
6.32 ~ 9.48 k Ω at 20°C

- Is the ignition coil OK?

YES

NO


Replace the ignition coil.

EAS00746

4. Ignition coil resistance

- Disconnect the ignition coil lead from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.

Tester positive probe → orange ①
Tester negative probe → ground ②




- Measure the primary coil resistance.



Primary coil resistance
0.18 ~ 0.28 Ω at 20°C

- Connect the pocket tester ($\Omega \times 1k$) to the ignition coil as shown.
- Measure the secondary coil resistance.

Tester positive probe → spark plug lead ①
Tester negative probe → orange ②




EAS00748

5. Pickup coil resistance

- Disconnect the pickup coil coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the pickup coil terminal as shown.

Tester positive probe → red ①
Tester negative probe → white ②



- Measure the pickup coil resistance.



Pickup coil resistance
656 ~ 984 Ω at 20°C
(between red and white)

- Is the pickup coil OK?

YES

NO


Replace the pickup coil.



6. Source coil resistance

- Disconnect the source coil coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 100$) to the charging coil terminal as shown.

Tester positive probe → **brown** ①
Tester negative probe → **green** ②



- Measure the source coil resistance.



Source coil resistance:
624 ~ 936 Ω (20°C)
(between brown and green)

- Is the source coil OK?

↓ YES

↓ NO

Replace the source coil.

EAS00749

7. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EAS00750

8. Engine stop switch

- Check the engine stop switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the engine stop switch OK?

↓ YES

↓ NO

Replace the right handlebar switch.

EAS00752

9. Sidestand switch

- Check the sidestand switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the sidestand switch OK?

↓ YES

↓ NO

Replace the side-stand switch.

10. Neutral relay

- Check the neutral relay for continuity. Refer to "ELECTRIC STARTING SYSTEM".
- Is the neutral relay OK?

↓ YES

↓ NO

Replace the neutral relay.

EAS00751

11. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

↓ YES

↓ NO

Replace the neutral switch.


12. Diode

• Disconnect the diode from the coupler.

• Connect the pocket tester ($\Omega \times 1$) to the diode terminals as shown.

• Measure the diode for continuity as follows.

Tester positive probe → blue/white ①	Continuity
Tester negative probe → blue/black ②	
Tester positive probe → blue/black ①	No continuity
Tester negative probe → blue/white ②	



NOTE:

When you switch the “-” and “+” leads of the digital pocket tester the readings in the above chart will be reversed.

• Are the tester readings correct?

YES

NO

Replace the relay unit.

EAS00766

13. Wiring

• Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".

• Is the ignition system's wiring properly connected and without defects?

NO

YES

Properly connect or repair the ignition system's wiring.


Replace the CDI unit.


7-11



EAS00755

ELECTRIC STARTING SYSTEM CIRCUIT DIAGRAM





EAS00756

STARTING CIRCUIT CUTOFF SYSTEM OPERATION


If the engine stop switch is set to "⌚" and the main switch is set to "ON" (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The transmission is in neutral (the neutral switch is closed).
- The clutch lever is pulled to the handlebar (the clutch switch is closed) and the sidestand is up (the sidestand switch is closed).

The neutral relay prevents the starter motor from operating when neither of these conditions has been met. In this instance, the neutral relay is open so current cannot reach the starter motor. When at least one of the above conditions has been met the neutral relay is closed and the engine can be started by pressing the start switch.

-  WHEN THE TRANSMISSION IS IN NEUTRAL
 WHEN THE SIDESTAND IS UP AND THE CLUTCH LEVER IS PULLED TO THE HANDLEBAR

- ① Battery
- ② Main fuse
- ③ Main switch
- ④ Engine stop switch
- ⑤ Neutral relay
- ⑥ Clutch switch
- ⑦ Sidestand switch
- ⑧ Neutral switch
- ⑨ Start switch
- ⑩ Starter relay
- ⑪ Starter motor





EAS00757

TROUBLESHOOTING

The starter motor fails to turn.

Check:

1. fuse
 2. battery
 3. starter motor
 4. neutral relay
 5. starter relay
 6. main switch
 7. engine stop switch
 8. neutral switch
 9. sidestand switch
 10. clutch switch
 11. start switch
 12. wiring
- (of the entire starting system)

NOTE:

- Before, troubleshooting, remove the following part(-s):
 - 1) side covers (left and right)
 - 2) seat
 - 3) fuel tank
- Troubleshoot with the following special tool(-s).



Pocket tester
90890-03112

EAS00738

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE FUSES" in chapter 3.
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse(-s).

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Specific gravity:
1.280 at 20°C

- Is the battery OK?

↓ YES


↓ NO

- Refill the battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EAS00758

3. Starter motor

- Connect the battery positive terminal ① and starter motor lead ② with a jumper lead ③.

**⚠ WARNING**

- A wire that is used as a jumper lead must have at least the same capacity of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore make sure that no flammable gas or fluid is in the vicinity.

- Does the starter motor turn?

↓ YES

↓ NO

Repair or replace the starter motor.




4. Neutral relay

- Disconnect the relay unit from the coupler.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the relay unit terminals as shown.

Battery positive terminal → brown ①
Battery negative terminal → sky blue ②

Tester positive probe → blue/white ③
Tester negative probe → black/white ④



- Does the starting circuit cutoff relay have continuity between black/white and blue/white?

↓ YES

↓ NO

Replace the relay unit.


EAS00761

5. Starter relay

- Disconnect the starter relay from the coupler.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the starter relay coupler as shown.

Battery positive terminal → red/white ①
Battery negative terminal → brown ②

Tester positive probe → red ③
Tester negative probe → black ④



- Does the starter relay have continuity between red and check?

↓ YES

↓ NO

Replace the starter relay.

EAS00749

6. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EAS00750

7. Engine stop switch

- Check the engine stop switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the engine stop switch OK?

↓ YES

↓ NO

Replace the right handlebar switch.

ELECTRIC STARTING SYSTEM

ELEC

EAS00751

8. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

↓ YES

↓ NO

Replace the neutral switch.

EAS00752

9. Sidestand switch

- Check the sidestand switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the sidestand switch OK?

↓ YES

↓ NO

Replace the side-stand switch.

EAS00763

10. Clutch switch

- Check the clutch switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the clutch switch OK?

↓ YES

↓ NO

Replace the clutch switch.

EAS00764

11. Start switch

- Check the start switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the start switch OK?

↓ YES

↓ NO

Replace the right handlebar switch.

EAS00766

12. Wiring

- Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the starting system's wiring properly connected and without defects?

↓ NO


↓ YES

Properly connect or repair the starting system's wiring.



The starting system circuit is OK.



STARTER MOTOR



Order	Job name/Part name	Q'ty	Remarks
	Starter motor removal Drain the engine oil		Remove the parts in order. Refer to "ENGINE OIL REPLACEMENT" in CHAPTER 3.
1	Starter motor lead	1	
2	Starter motor	1	
3	O-ring	1	Reverse the removal procedure for installation.
	Starter motor disassembly		Disassemble the parts in order.
①	Front cover	1	
②	Washer set	1	
③	Rear cover	1	Refer to "Assembly" section.
④	Armature coil	1	
⑤	Brush	1	Reverse the disassembly procedure for assembly.



EAS00769

Checking the starter motor

1. Check:
 - commutator
Dirt → Clean with 600 grit sandpaper.
2. Measure:
 - commutator diameter (a)
Out of specification → Replace the starter motor.



Min. commutator diameter
21 mm


- ### 3. Measure:
- mica undercut (a)
Out of specification → Scrape the mica to the proper measurement with a hacksaw blade which has been grounded to fit the commutator.



**Mica undercut
1.5 mm**

NOTE:

The mica must be undercut to ensure proper operation of the commutator.



4. Measure:
- armature assembly resistances (commutator and insulation)
- Out of specification → Replace the starter motor.

- a. Measure the armature assembly resistances with the pocket tester.




Pocket tester
90890-03112



Armature assembly
Commutator resistance ①
0.0171 ~ 0.0209 Ω at 20°C
Insulation resistance ②
Above 1 M Ω at 20°C

- b. If any resistance is out of specification, replace the starter motor.




5. Measure:

- brush length ①

Out of specification → Replace the brushes as a set.



Min. brush length
3.5 mm



6. Measure:

- brush spring free length (Compressed spring) ①

Out of specification → Replace the brush springs as a set.



Brush spring
14.5 mm

7. Check:


- gear teeth

Damage/wear → Replace the gear.

8. Check:

- bearing
- oil seal

Damage/wear → Replace the defective part(-s).



EAS00772


Assembling the starter motor

1. Install:

- washer set

NOTE:

Align the tabs ① on the washer with the slots ② in the starter motor front cover.



2. Install:

- starter motor yoke ①
- O-rings ② **New**
- starter motor front cover ③
- starter motor rear cover ④
- bolts



5 Nm (0.5 m•kg)

NOTE:

Align the match marks ① on the starter motor yoke with the match marks ② on the front and rear covers.



EAS00774

TROUBLESHOOTING

The battery is not being charged.

Check:

1. fuse
2. battery
3. charging voltage
4. stator coil assembly resistance
5. wiring
(of the entire charging system)

NOTA:

- Before troubleshooting, remove the following part(-s):
 - 1) side covers (left and right)
 - 2) seat
- Troubleshoot with the following special tool(-s).



Engine tachometer

90890-03113

Pocket tester

90890-03112

EAS00738

1. Fuse

- Check the main fuses for continuity. Refer to "CHECKING THE FUSES" in chapter 3.
- Is the main fuses OK?



YES



NO

Replace the fuse.

2. Battery

- Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Specific gravity

1.280 at 20°C

- Is the battery OK?



YES



NO

- Refill the battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EAS00775

3. Charging voltage


- Connect the engine tachometer to the spark plug lead.
- Connect the pocket tester (DC 20 V) to the battery as shown.

Tester positive probe →

battery positive terminal

Tester negative probe →

battery negative terminal



- Start the engine and let it run at approximately 5,000 r/min.
- Measure the charging voltage.



Charging voltage

14.5 V at 5,000 r/min

NOTE:

Make sure that the battery is fully charged.

- Is the charging voltage within specification?




NO



YES

The charging circuit is OK.



EB804401

4. Stator coil assembly resistance


- Disconnect the starter coil coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the stator coil assembly coupler as shown.

Tester positive probe → white ①

Tester negative probe → white ②

Tester positive probe → white ①

Tester negative probe → white ③



- Measure the stator coil assembly resistances.



Stator coil resistance

0.48 ~ 0.72 Ω at 20°C

- Is the stator coil assembly OK?

YES

NO

Replace the stator coil assembly.

EB804404

5. Wiring

- Check the wiring connections of the entire charging system.
Refer to "CIRCUIT DIAGRAM".
- Is the charging system's wiring properly connected and without defects?

NO

YES


Properly connect or repair the charging system's wiring.

Replace the rectifier/regulator.



EB804000

LIGHTING SYSTEM CIRCUIT DIAGRAM





EAS00781

TROUBLESHOOTING

Any of the following fail to light: head light, high beam indicator light, taillight, auxiliary light or meter light.

Check:

1. fuse
2. battery
3. main switch
4. lights switch
5. dimmer switch
6. wiring
(of the entire charging system)

NOTE:

- Before troubleshooting, remove the following part(-s):
 - 1) side covers (left and right)
 - 2) seat
 - 3) fuel tank
- Troubleshoot with the following special tool(-s).



Pocket tester
90890-03112

EAS00738

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE FUSES" in chapter 3.
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse(-s).

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Specific gravity
1.280 at 20 °C

- Is the battery OK?

↓ YES

↓ NO

- Refill the battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EAS00749

3. Main switch

- Check the main switch for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EAS00783

4. Lights switch

- Check the lights switch for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the lights switch OK?

↓ YES

↓ NO

The lights switch is faulty. Replace the right handlebar switch.



EAS00784

5. Dimmer switch

- Check the dimmer switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the dimmer switch OK?

YES

NO

The dimmer switch is faulty. Replace the left handlebar switch.

EAS00787

7. Wiring

- Check the entire lighting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the lighting system's wiring properly connected and without defects?

YES

NO

Check the condition of each of the lighting system's circuits. Refer to "CHECKING THE LIGHTING SYSTEM".

Properly connect or repair the lighting system's wiring.

EAS00788

CHECKING THE LIGHTING SYSTEM

1. The headlight and the high beam indicator light fail to come on.

1. Headlight bulb and socket

- Check the headlight bulb and socket for continuity. Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the headlight bulb and socket OK?

YES


NO

Replace the headlight bulb, socket or both.

2. Voltage

- Connect the pocket tester (DC 20 V) to the headlight and high beam indicator light couplers as shown.

- A** When the dimmer switch is set to "D".
B When the dimmer switch is set to "D".





Headlight

Tester positive probe →


yellow ① or green ②

Tester negative probe → black ③

High beam indicator light

Tester positive probe → yellow ④

Tester negative probe → black ⑤



- Set the main switch to "ON".
- Set the light switch to "☀".
- Set the dimmer switch to "☹" or "☹".
- Measure the voltage (12 V) of yellow (green) ② on the headlight coupler (headlight side).
- Is the voltage within specification?

YES

This circuit is OK.

NO


The wiring circuit from the main switch to the headlight coupler is faulty and must be repaired.

2. Voltage

- Connect the pocket tester (20 V) to the meter assembly coupler (wire harness side) as shown.

Tester positive probe → blue ①

Tester negative probe → black ②



- Set the main switch to "ON".
- Set the light switch to "☹" or "☹".
- Measure the voltage (12 V) of blue ① on the meter assembly coupler (wire harness side).
- Is the voltage within specification?

YES

This circuit is OK.

NO

The wiring circuit from the main switch to the meter assembly coupler is faulty and must be repaired.

EAS00789

2. A meter light fails to come on.

1. Meter light bulb and socket

- Check the meter light bulb and socket for continuity. Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the meter light bulb and socket OK?

YES

NO

Replace the meter light bulb, socket or both.



EAS00790

3. A tail/brake light fails to come on.

1. Tail/brake light bulb and socket

- Check the tail/brake light bulb and socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the tail/brake light bulb and socket OK?




Replace the tail/brake light bulb, socket or both.

2. Voltage

- Connect the pocket tester (DC 20 V) to the tail/brake light coupler (wire harness side) as shown.

Tester positive probe → blue ①
Tester negative probe → black ②



- Set the main switch to "ON".
- Set the light switch to "ON" or "OFF".
- Measure the voltage (12 V) of blue ① on the tail/brake light coupler (wire harness side).
- Is the voltage within specification?



This circuit is OK.

The wiring circuit from the main switch to the tail/brake light coupler is faulty and must be repaired.

EAS00791

4. The auxiliary light fails to come on.

1. Auxiliary light bulb and socket

- Check the auxiliary light bulb and socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the auxiliary light bulb and socket OK?




Replace the auxiliary light bulb, socket or both.

2. Voltage

- Connect the pocket tester (DC 20 V) to the auxiliary light couplers (wire harness side) as shown.

Tester positive probe → blue/red ①
Tester negative probe → black ②



- Set the main switch to "ON".
- Set the light switch to "ON" or "OFF".
- Measure the voltage (12 V) of blue/red ① on the auxiliary light couplers (wire harness side).
- Is the voltage within specification?




This circuit is OK.

The wiring circuit from the main switch to the auxiliary light connectors is faulty and must be repaired.



EB806000

SIGNAL SYSTEM CIRCUIT DIAGRAM





EAS00794

TROUBLESHOOTING

- Any of the following fail to light: turn signal light, brake light or an indicator light.
- The horn fails to sound.

Check:

1. fuse
2. battery
3. main switch
4. wiring
(of the entire signaling system)

NOTE:

- Before troubleshooting, remove the following part(-s):
 - 1) side covers (left and right)
 - 2) seat
 - 3) fuel tank
- Troubleshoot with the following special tool(-s).



Pocket tester
90890-03112

EAS00738

1. Fuse

- Check the fuse for continuity. Refer to "CHECKING AND CHARGING THE FUSES" in chapter 3.
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse(-s).

2. Battery

- Check the condition of the battery. Refer to "CHECKING THE BATTERY" in chapter 3.



Specific gravity
1.280 at 20°C

- Is the battery OK?

↓ YES

↓ NO

- Refill the battery fluid.
- Clean the battery terminals.
- Recharge or replace the battery.

EAS00749

3. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EAS00795

4. Wiring

- Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the signaling system's wiring properly connected and without defects?

↓ YES

↓ NO

Check the condition of each of the signaling system's circuits. Refer to "CHECKING THE SIGNALING SYSTEM".

Properly connect or repair the signaling system's wiring.



EAS00796

CHECKING THE SIGNALING SYSTEM

1. The horn fails to sound.

1. Horn switch

- Check the horn switch for continuity. Refer to “CHECKING THE SWITCHES”.
- Is the horn switch OK?



YES




NO

Replace the left handlebar switch.

2. Voltage

- Connect the pocket tester (DC 20 V) to the horn connector at the horn terminal as shown.

Tester positive probe → brown ①
Tester negative probe → ground



- Set the main switch to “ON”.
- Push the horn switch.
- Measure the voltage (12 V) of brown at the horn terminal.
- Is the voltage within specification?



YES




NO

The wiring circuit from the main switch to the horn connector is faulty and must be repaired.

3. Horn

- Disconnect the pink connector at the horn terminal.
- Connect a jumper lead ① to the horn terminal and ground the jumper lead.
- Set the main switch to “ON”.
- Push the horn switch.
- Does the horn sound?



NO




YES

The horn is OK.

4. Voltage

- Connect the pocket tester (DC 20 V) to the horn connector at the black terminal as shown.

Tester positive probe → pink ①
Tester negative probe → ground



- Set the main switch to “ON”.
- Measure the voltage (12 V) of pink ① at the horn terminal.
- Is the voltage within specification?



YES



NO

Repair or replace the horn.

Replace the horn.



EAS00797

2. A tail/brake light fails to come on.

1. Tail/brake light bulb and socket

- Check the tail/brake light bulb and socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the tail/brake light bulb and socket OK?

↓ YES

↓ NO

Replace the tail/brake light bulb, socket or both.

2. Brake light switches

- Check the brake light switches for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the brake light switch OK?

↓ YES


↓ NO

Replace the brake light switch.

3. Voltage

- Connect the pocket tester (DC 20 V) to the tail/brake light coupler (wire harness side) as shown.

Tester positive probe → yellow ①
Tester negative probe → black ②



- Set the main switch to "ON".
- Pull in the brake lever or push down on the brake pedal.
- Measure the voltage (12 V) of yellow at the tail/brake light coupler (wire harness side).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.

The wiring circuit from the main switch to the tail/brake light coupler is faulty and must be repaired.

EAS00799

3. A turn signal light, turn signal indicator light or both fail to blink.

1. Turn signal light bulb and socket

- Check the turn signal light bulb and socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the turn signal light bulb and socket OK?

↓ YES

↓ NO

Replace the turn signal light bulb, socket or both.

3. Turn signal switch

- Check the turn signal switch for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the turn signal switch OK?

↓ YES

↓ NO


Replace the left handlebar switch.



4. Voltage

- Connect the pocket tester (DC V 20) to the flasher relay coupler (wire harness side) as shown.

Tester positive probe → brown ①
Tester negative probe → ground



- Set the main switch to "ON".
- Measure the voltage (12 V) of brown ① at the flasher relay coupler (wire harness side).
- Is the voltage within specification?

↓ YES


↓ NO

The wiring circuit from the main switch to the flasher relay coupler (flasher relay side) is faulty and must be repaired.

5. Voltage

- Connect the pocket tester (DC 20 V) to the flasher relay coupler (wire harness side) as shown.

Tester positive probe → brown/white ①
Tester negative probe → ground



- Set the main switch to "ON".
- Measure the voltage (12 V) on brown/white at the flasher relay coupler (wire harness side).
- Is the voltage within specification?

↓ YES

↓ NO

The flasher relay is faulty and must be replaced.

6. Voltage

- Connect the pocket tester (DC 20 V) to the turn signal light connectors or the meter assembly coupler (wire harness side) as shown.

- A** Turn signal light
- B** Turn signal indicator light

Left turn signal light



Tester positive probe → chocolate (orange) ①
Tester negative probe → ground

Right turn signal light

Tester positive probe → dark green ②
Tester negative probe → ground

Turn signal indicator light

Tester positive probe → brown ③
Tester negative probe → brown/white ④





- Set the main switch to “ON”.
- Set the turn switch to “↶” or “↷”.
- Measure the voltage (12 V) of chocolate (orange) ① or dark green ② at the turn signal light connector (wire harness side).
- Is the voltage within specification?

YES

NO

This circuit is OK.

The wiring circuit from the turn signal switch to the turn signal light connector is faulty and must be repaired.

EAS00800

4. The neutral indicator light fails to come on.

1. Neutral indicator light bulb and socket

- Check the neutral indicator light bulb and socket for continuity.
- Are the neutral indicator light bulb and socket OK?

YES

NO

Replace the neutral indicator bulb, socket or both.

2. Neutral switch

- Check the neutral switch for continuity. Refer to “CHECKING THE SWITCHES”.
- Is the neutral switch OK?

YES

NO


Replace the neutral switch.

3. Voltage

- Connect the pocket tester (DC 20 V) to the meter assembly coupler (wire harness side) as shown.

Tester positive probe → brown ①

Tester negative probe → sky blue ②



- Set the main switch to “ON”.
- Measure the voltage (12 V) of brown ① and sky blue ② at the meter assembly coupler.
- Is the voltage within specification?

YES

NO

This circuit is OK.

The wiring circuit from the main switch to the meter light bulb coupler is faulty and must be repaired.


5. The carburetor heater fails to come on.

1. Thermo switch


- Disconnect the thermo switch from the wire-harness..
- Connect the pocket tester ($\Omega \times 1$) to the thermo switch lead.

Tester positive probe → black ①

Tester negative probe → black ②



- Check the thermo switch for continuity at the temperatures indicated below.



A COOL DOWN

B HEAT UP

- Does the thermo switch operated properly?

↓ YES

↓ NO

Replace the thermo switch.

- Measure the carburetor heater resistance.



Carburetor heating element resistance:

6 ~ 12 Ω (20°C)

- Is the carburetor heating element OK?

↓ YES

↓ NO


This circuit is OK.

Replace the carburetor heater element.

2. Carburetor heater

- Remove the carburetor heating element from the carburetor.
- Connect the pocket tester ($\Omega \times 1$) to the carburetor heating element.

Tester positive probe → heating element ①
Tester negative probe → heating element body ②



?

TRBL
SHTG

8

CHAPTER 8. TROUBLESHOOTING

STARTING PROBLEMS	8-1
INCORRECT ENGINE IDLING SPEED	8-2
POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE	8-2
FAULTY GEAR SHIFTING	8-2
FAULTY CLUTCH	8-3
OVERHEATING	8-3
POOR BRAKING PERFORMANCE	8-4
FAULTY FRONT LEGS	8-4
UNSTABLE HANDLING	8-4
FAULTY LIGHTING AND SIGNALING SYSTEMS	8-5

TROUBLESHOOTING

NOTE:

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

STARTING PROBLEMS**ENGINE****Cylinders and cylinder head(-s)**

- Loose spark plug
- Loose cylinder head
- Damaged cylinder head gasket
- Worn or damaged cylinder
- Incorrect valve clearance
- Incorrectly sealed valve
- Incorrect valve-to-valve-seat contact
- Incorrect valve timing
- Faulty valve spring
- Seized valve

Pistons and piston rings

- Incorrectly installed piston ring
- Damaged, worn or fatigued piston ring
- Seized piston ring
- Seized or damaged piston

Air filter

- Incorrectly installed air filter
- Clogged air filter element

Crankcase and crankshaft

- Incorrectly assembled crankcase
- Seized crankshaft

FUEL SYSTEM**Fuel tank**

- Empty fuel tank
- Clogged fuel filter
- Clogged fuel tank breather hole
- Deteriorated or contaminated fuel

Fuel cock

- Clogged or damaged fuel hose

Carburetors

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Damaged float
- Worn needle valve
- Incorrectly installed needle valve seat
- Incorrect fuel level
- Incorrectly installed pilot jet
- Clogged starter jet
- Faulty starter plunger
- Incorrectly adjusted starter cable

ELECTRICAL SYSTEMS**Battery**

- Faulty battery
- Discharged battery

Fuse

- Blown, damaged or incorrect fuse
- Incorrectly installed fuse

Spark plug

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil

- Damaged ignition coil
- Broken or shorted primary or secondary coils
- Faulty spark plug lead

Ignition system

- Faulty CDI unit
- Faulty pickup coil

Switches and wiring

- Faulty main switch
- Faulty engine stop switch
- Broken or shorted wiring
- Faulty neutral switch
- Faulty start switch
- Faulty sidestand switch
- Faulty clutch switch
- Incorrectly grounded circuit
- Loose connections

Starting system

- Faulty starter motor
- Faulty starter relay
- Faulty neutral relay
- Faulty starter clutch

EAS00846

INCORRECT ENGINE IDLING SPEED

ENGINE

Cylinders and cylinder head

- Incorrect valve clearance
- Damaged valve train components

Air filter

- Clogged air filter element

FUEL SYSTEM

Carburetor

- Faulty starter plunger
- Loose or clogged pilot jet
- Loose or clogged pilot air jet
- Damaged or loose carburetor joint
- Incorrectly adjusted engine idling speed (throttle stop screw)
- Incorrect throttle cable free play
- Flooded carburetor

ELECTRICAL SYSTEMS

Battery

- Faulty battery
- Discharged battery

Spark plug

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil

- Broken or shorted primary or secondary coils
- Faulty spark plug lead
- Damaged ignition coil

Ignition system

- Faulty CDI unit
- Faulty pickup coil

EAS00848

POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING PROBLEMS".

ENGINE

Air filter

- Clogged air filter element

FUEL SYSTEM

Carburetors

- Faulty diaphragm
- Incorrect fuel level
- Loose or clogged main jet

EAS00850

FAULTY GEAR SHIFTING

SHIFTING IS DIFFICULT

Refer to "CLUTCH DRAGS".

SHIFT PEDAL DOES NOT MOVE

Shift shaft

- Incorrectly adjusted shift rod
- Bent shift shaft

Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Foreign object between transmission gears
- Incorrectly assembled transmission

JUMPS OUT OF GEAR

Shift shaft

- Incorrect shift pedal position
- Incorrectly returned stopper lever

Shift forks

- Worn shift fork

Shift drum

- Incorrect axial play
- Worn shift drum groove

Transmission

- Worn gear dog

EAS00851

FAULTY CLUTCH

CLUTCH SLIPS

Clutch

- Incorrectly assembled clutch
- Incorrectly adjusted clutch cable
- Loose or fatigued clutch spring
- Worn friction plate
- Worn clutch plate

Engine oil

- Incorrect oil level
- Incorrect oil viscosity (low)
- Deteriorated oil

CLUTCH DRAGS

Clutch

- Unevenly tensioned clutch spring
- Warped pressure plate
- Bent clutch plate
- Swollen friction plate
- Bent clutch push rod
- Damaged clutch boss
- Burnt primary driven gear bushing
- Match marks not aligned

Engine oil

- Incorrect oil level
- Incorrect oil viscosity (high)
- Deteriorated oil

EAS00854

OVERHEATING

ENGINE

Cylinder head(-s) and piston(-s)

- Heavy carbon buildup

Engine oil

- Incorrect oil level
- Incorrect oil viscosity
- Inferior oil quality

FUEL SYSTEM

Carburetors

- Incorrect main jet setting
- Incorrect fuel level
- Damaged or loose carburetor joint

Air filter

- Clogged air filter element

CHASSIS

Brakes

- Dragging brake

ELECTRICAL SYSTEMS

Spark plugs

- Incorrect spark plug gap
- Incorrect spark plug heat range

Ignition system

- Faulty CDI unit

EAS00859

POOR BRAKING PERFORMANCE

Front brake

- Worn brake pad
- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper piston seal
- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

Rear brake

- Improper brake pedal adjustment
- Worn brake shoe
- Improper brake shoe contact
- Worn camshaft
- Worn brake drum
- Mud or water into brake drum inside
- Oily or greasy brake lining
- Faulty brake cable
- Broken or fatigued tension spring
- Faulty camshaft, cam lever

EAS00861

FAULTY FRONT FORK LEGS

LEAKING OIL

- Bent, damaged or rusty inner tube
- Damaged outer tube
- Incorrectly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- Loose damper rod assembly bolt
- Damaged damper rod assembly, bolt, or copper washer
- Damaged cap bolt O-ring

MALFUNCTION

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube busing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

EAS00864

UNSTABLE HANDLING

Handlebar

- Bent or incorrectly installed handlebar

Steering head components

- Incorrectly installed upper bracket
- Incorrectly installed lower bracket (incorrectly tightened ring nut)
- Bent steering stem
- Damaged ball bearing or bearing race

Front fork legs

- Uneven oil levels (both front fork legs)
- Unevenly tensioned fork spring (both front fork legs)
- Damaged fork spring
- Bent or damaged inner tube
- Bent or damaged outer tube

Swingarm

- Worn bearing or bushing
- Bent or damaged swingarm

Rear shock absorber assembly

- Faulty rear shock absorber spring
- Leaking oil or gas

Tires

- Uneven tire pressures (front and rear)
- Incorrect tire pressure
- Uneven tire wear

Wheels

- Incorrect wheel balance
- Loose sporks
- Deformed wheel rim
- Damaged wheel bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent frame
- Damaged steering head pipe
- Incorrectly installed bearing race

EAS00866

FAULTY LIGHTING AND SIGNALING SYSTEMS

HEADLIGHT DOES NOT LIGHT

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging
- Incorrect connection
- Incorrectly grounded circuit
- Poor contacts (main or light switch)
- Burnt-out headlight bulb

HEADLIGHT BULB BURNT OUT

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Incorrectly grounded circuit
- Faulty main switch
- Faulty light switch
- Headlight bulb life expired

TAIL/BRAKE LIGHT DOES NOT LIGHT

- Wrong tail/brake light bulb
- Too many electrical accessories
- Incorrect connection
- Burnt-out tail/brake light bulb

TAIL/BRAKE LIGHT BULB BURNT OUT

- Wrong tail/brake light bulb
- Faulty battery
- Incorrectly adjusted rear brake light switch
- Tail/brake light bulb life expired

TURN SIGNAL DOES NOT LIGHT

- Faulty turn signal switch
- Faulty flasher relay
- Burnt-out turn signal bulb
- Incorrect connection
- Damaged or faulty wire harness
- Incorrectly grounded circuit
- Faulty battery
- Blown, damaged or incorrect fuse

TURN SIGNAL BLINKS SLOWLY

- Faulty flasher relay
- Faulty main switch
- Faulty turn signal switch
- Wrong turn signal bulb

TURN SIGNAL REMAINS LIT

- Faulty flasher relay
- Burnt-out-turn signal bulb

TURN SIGNAL BLINKS QUICKLY


- Incorrect turn signal bulb
- Faulty flasher relay
- Burnt-out turn signal bulb

HORN DOES NOT SOUND

- Incorrectly adjusted horn
- Damaged or faulty horn
- Faulty main switch
- Faulty horn switch
- Faulty battery
- Blown, damaged or incorrect fuse
- Faulty wire harness

TRBL SHTG	?
--------------	---

TW125 '99 WIRING DIAGRAM



- ① C.D.I. magneto
- ② Neutral switch
- ③ Rectifier/Regulator
- ④ Battery
- ⑤ Starter relay
- ⑥ Fuse
- ⑦ Starting motor
- ⑧ Handlebar switches (right)
- ⑨ Start switch
- ⑩ Engine stop switch
- ⑪ Main switch
- ⑫ Clutch switch
- ⑬ Diode
- ⑭ C.D.I. unit
- ⑮ Ignition coil
- ⑯ Spark plug
- ⑰ Thermo switch
- ⑱ Carburetor heater
- ⑲ Horn
- ⑳ Flasher relay
- ㉑ Sidestand switch
- ㉒ Neutral relay
- ㉓ Speedometer
- ㉔ Reed switch (for D[5EK2])
- ㉕ Meter light
- ㉖ Neutral indicator light
- ㉗ Turn signal indicator light
- ㉘ Hi-beam indicator light
- ㉙ Handlebar switches (left)
- ㉚ Horn switch
- ㉛ Turn switch
- ㉜ Lights switch
- ㉝ Dimmer switch
- ㉞ Front brake switch
- ㉟ Rear brake switch
- ㊱ Rear turn signal light (right)
- ㊲ Front turn signal light (right)
- ㊳ Front turn signal light (left)
- ㊴ Rear turn signal light (left)
- ㊵ Headlight
- ㊶ Auxiliary light
- ㊷ Tail/Brake light

COLOR CODE

B Black
Br Brown
Ch ... Chocolate
Dg ... Dark green
G Green
L Blue
O Orange

Sb Sky blue
P Pink
R Red
Y Yellow
W White
B/R Black/Red
B/W Black/White

Br/L .. Brown/Blue
Br/W .. Brown/White
G/R .. Green/Red
G/W .. Green/White
G/Y .. Green/Yellow
L/B ... Blue/Black
L/R ... Blue/Red

L/W .. Blue/White
L/Y ... Blue/Yellow
R/L ... Red/Blue
R/W .. Red/White
W/B .. White/Black
W/L .. White/Blue
W/R .. White/Red